



—
USER GUIDE

Sensi+

GLA533-NG Gas Analyzer



Disclaimer

This Guide and any accompanying software are copyrighted and all rights are reserved by ABB. This product, including software and documentation, may not be copied, photocopied, reproduced, translated, or reduced, in whole or in part, to any electronic medium or machine-readable format without prior written consent from ABB.

This document contains product specifications and performance statements that may be in conflict with other ABB published literature, such as product fliers and catalogs. All specifications, product characteristics, and performance statements included in this document are given as indications only. In case of discrepancies between specifications given in this document and specifications given in the official ABB product catalogs, the latter takes precedence.

ABB reserves the right to make changes to the specifications of all equipment and software, and contents of this document, without obligation to notify any person or organization of such changes. Every effort has been made to ensure that the information contained in this document is current and accurate. However, no guarantee is given or implied that the document is error-free or that the information is accurate.

ABB makes no representations or warranties with regard to the product and instructional and reference materials, including, but not limited to, all implied warranties of merchantability and fitness for a particular purpose.

ABB does not warrant, guarantee, or make any representations regarding the use, or the results of the use, of any software or written materials in terms of correctness, accuracy, reliability, currentness, or otherwise. ABB shall not be liable for errors or omissions contained in its software or manuals, any interruptions of service, loss of business or anticipatory profits and/or for incidental or consequential damages in connection with the furnishing, performance or use of these materials, even if ABB has been advised of the possibility of such damages.

All equipment, software, and manuals are sold as is. The entire risk as to the results and performance of the equipment and software is assumed by the user.

The software or hardware described in this document is distributed under a license and may be used, copied, or disclosed only in accordance with the terms of such license.

© ABB, 2023

© Microsoft and Excel are registered trademarks of Microsoft Corporation

Table of Contents

1 Connecting to Sensi+	1	4 Managing Alarms	35
Connecting to the Analyzer	2	Introducing NAMUR and Process Alarm	
Connecting Locally	2	Conventions	35
Connecting Remotely	3	Displaying Alarms	37
Logging Into the Analyzer	4	Sorting Alarms	38
2 Introducing the Sensi+ Gas Analyzer Software	7	Acknowledging Alarms	39
Graphical User Interface	8	Acknowledging One Alarm	39
Top Bar	8	Acknowledging More Than One Alarm	40
Sidebar	8	Acknowledging All Alarms at Once	41
Bottom Bar	9	Filtering Alarms	42
Main Panel	9	Filtering by Alarm Status	42
3 Configuring Sensi+	11	Filtering by Priority	43
Changing Default Administrator Password	11	Filtering by Alarm Type	44
Changing Analyzer Date and Time	13	Filtering by Time Period	46
Naming Your Analyzer	14	Exporting Alarms	47
Configuring Gas Measurement Units	15	5 Managing Events.....	49
Configuring the Temperature Unit	16	Displaying Events	49
Configuring Gas Parameters	17	Sorting Events	49
Configuring the Display Range	18	Acknowledging Events	50
Configuring Alarm Thresholds	20	Acknowledging One Event	50
Modifying Zero Offsets and Span Gains	22	Acknowledging More Than One Event	51
Changing the H ₂ S High High Alarm Delay	22	Acknowledging All Events at Once	52
Configuring Internal Connectors	23	Filtering Events	53
Modifying the Client Ethernet Port		Filtering by Event Status	53
Configuration	23	Filtering by Priority	54
Modifying the Service Ethernet Port		Filtering by Time Period	55
Configuration	25	Exporting Events	57
Configuring Output Connectors	26	6 Managing Reports	59
Configuring Wi-Fi Connections (optional)	28	Generating Reports	59
Changing the Wi-Fi Password	28	Downloading Reports	61
Disabling/Enabling Wi-Fi connections	29	7 Troubleshooting and Maintenance... ..	63
Configuring User Profiles	30	Diagnosing Problems	63
Creating a User Profile	30	Resetting the Analyzer After Triggered Digital Output	64
Modifying a User Profile	32	Rebooting the Analyzer	65
Deleting a User Profile	33	Performing Analyzer Validation	66

Exporting Service Logs.....	67	E Technical Specifications.....	E109
Performing Advanced Troubleshooting.....	68	Measurement Specifications	E109
Servicing Analyzer Parts.....	69	Electrical Specifications	E109
Replacing the Gas Cell	69	Environmental Specifications.....	E110
Replacing the Pump Manifold	70	Mechanical Specifications	E110
About Your Sensi+ Gas Analyzer.....	71	Laser	E110
Backing Up the Analyzer System.....	73	Communication.....	E110
Installing Software Updates.....	75		
A The Local Graphical User Interface A79			
Information Panels	A80		
Measurements Panel	A80		
Non-Linear Trend Panels	A81		
Linear Trend Panels	A82		
Alarms.....	A83		
Diagnostics.....	A84		
System Information.....	A85		
B Digital Output Logic and Wiring.....B87			
Logic	B87		
Wiring	B87		
C Modbus Table	C89		
Table	C89		
Description Details.....	C101		
UnitID.....	C101		
WIC States	C101		
Bitfield PROCESS	C101		
Bitfield NAMUR.....	C102		
Bitfield QUALITY	C102		
Acquisition Error Registry	C102		
Events Registry.....	C102		
Bit Wise c155sx ERROR	C103		
Bit Wise c155sx STATUS.....	C103		
Bit Wise s350 ERROR.....	C103		
Bit Wise s350 STATUS	C104		
Bit Wise s370 ERROR.....	C104		
Bit Wise output420 STATUS.....	C104		
Bit Wise S370 output420 config	C104		
S370 serial config.....	C105		
TCP/IP Modbus parameters details	C106		
D Calculating Zero Offsets and Span Gains.....D107			
Obtaining Calculation Values	D107		
Calculating Gain Values.....	D107		
Calculating Offset Values	D107		

Connecting to Sensi+

Sensi+ is designed to be operational from the moment it comes online. Upon installation, the instrument is fully configured to work in a vast majority of gas analysis scenarios. However, situations might happen where you need to perform additional configurations and actions (adding users, extracting data, acknowledging system events, etc.). These configurations and actions are explained in this document.



NOTICE

All information related to the **physical** installation, connection, and troubleshooting of the Sensi+ gas analyzer can be found in the Sensi+ Installation and Commissioning Guide. Also, operators of this instrument should familiarize themselves with the content of the Sensi+ Product Safety Guide.

To perform these additional operations, you first need to connect to the instrument via either a wired (Ethernet) or wireless (Wi-Fi) connection.

You will find these connections procedures in this chapter.



NOTICE—CYBERSECURITY

This product is designed to be connected to, and communicate information and data via a network interface. It is the user's sole responsibility to provide, and continuously ensure, a secure connection between the product and the user's network or any other network (as the case may be).

Users shall establish and maintain any and all appropriate measures (such as, but not limited to, the installation of firewalls, the application of authentication measures, the encryption of data, the installation of anti-virus programs, etc.) to protect the product, the network, its system and the interface against any kind of security breaches, unauthorized accesses, interferences, intrusions, leakages and/or theft of data or information.

ABB and its affiliates are not liable for damages and/or losses related to such security breaches, any unauthorized access, interference, intrusion, leakage and/or theft of data or information.

ABB strives to maintain cybersecurity for its products and services. By visiting the web page, you will find notifications about newly found software vulnerabilities and options to download the latest software. It is recommended that you visit this web page regularly:

<http://new.abb.com/about/technology/cyber-security>

Information about your product is also available on the product page:

<https://bit.ly/3CHoNkE>

Connecting to the Analyzer

The first step is to establish a link (wired or wireless) between your computer and Sensi+. This link can be established locally (via Ethernet or Wi-Fi) or remotely.


The following sections explain each method.

Connecting Locally

There are two methods for connecting locally:

- Via the external Ethernet port
- Via Wi-Fi (optional)

Figure 1 Connections



Via the External Ethernet Port

To connect to the analyzer via the external Ethernet port:

- 1 Configure your laptop with the following fixed IP address:
 - Fixed IP Address: **10.0.0.x** (replace the **x** with any number except 0 or 1)
 - Subnet Mask: 255.255.255.0



DANGER

Before performing the next step, make sure that the area is properly derated.

- 2 Connect an Ethernet cable (Cat 5 type, minimum) between your computer and the Sensi+ external Ethernet port.
- 3 Launch your Web browser and point it to the following address: **https://10.0.0.1**
The Sensi+ web remote interface appears.

NOTE: You may need to confirm that you trust the site you are trying to access (REMOTE HMI) as the Security Certificate cannot be validated with your device.

Via Wi-Fi (Optional)

To connect to the analyzer via Wi-Fi (available if an antenna is present):

- 1 Make sure that Wi-Fi on your computer is active. By default, the analyzer Wi-Fi connection is enabled.
- 2 On your computer, in the list of available Wi-Fi connections, select the analyzer (e.g., **GLA533-xxxxxxxx**).
- 3 When you are asked to provide the Wi-Fi security password, enter **SensiplusWF!**
The Sensi+ web remote interface appears.

NOTE: The Wi-Fi password might have been modified upon commissioning of the analyzer. Make sure that you have the proper access information before trying to connect.

Connecting Remotely

Technically, once your computer is connected to the network shared with your analyzer, you are connected to your analyzer and you just need to log in as explained in the next section.


Logging Into the Analyzer

Once you are connected to the analyzer, you need log into it via its Web remote interface. The remote interface is accessible through most mainstream Web browsers. Sensi+ supports the latest versions of Chrome, Firefox, Edge, and Safari. **Chrome is strongly suggested.**

To log into the analyzer:

- 1 Point your Web browser to the correct address:
 - If you are connected locally, through the external Ethernet port, enter the IP address
`https://10.0.0.1`
 - If you are connected remotely via a network, enter the fixed IP address set during commissioning of the analyzer (refer to the Installation and Commissioning Guide for more information), or enter the IP address assigned by the DHCP server¹ (as displayed on the Sensi+ screen [see Figure 2]).²

Figure 2 Analyzer Address in the Web Browser



When your browser connects to the address entered, the Sensi+ application appears in the current browser tab.

¹ The address assigned by a DHCP server can be found on the Sensi+ analyzer screen or by scanning the network.

² It is suggested to bookmark this address for future references.

Figure 3 Sensi+ Gas Analyzer Application (administrator access rights)



NOTE: The interface that you see in Figure 3 might differ slightly, depending on your access rights.

- 2 Click the Login/Logout icon (see Figure 3).
- 3 In the dialog box that appears, enter your username and password.

NOTE: The default username and password should have been modified during analyzer commissioning. Refer to the Installation and Commissioning Guide for more information.

- 4 Click **Login**. The interface automatically adapts to your access rights (for more information on access rights, see Table 2 on page 31.)



NOTICE

Refreshing your Web page automatically logs you out.

Page intentionally left blank

CHAPTER 2

Introducing the Sensi+ Gas Analyzer Software

The Sensi+ gas analyzer application allows you to configure the analyzer, manage its data and user accesses, generate reports, and perform basic maintenance tasks.

When your browser connects to the address entered, the Sensi+ application screen appears in the main window.

NOTE: The interface that you see in Figure 4 below may be slightly different from the one that you see on your screen, depending on the user's access rights to the system. For more information, see "Configuring User Profiles" on page 30.

Figure 4 Sensi+ Gas Analyzer Application Screen (logged in as an administrator)




Graphical User Interface

The following pages provide an overview of the main areas of the Sensi+ application graphical user interface (GUI).

Top Bar

The application top bar displays two icons illustrating Process and NAMUR alarm categories. A number above one of these icons indicates the number of current alarms for the alarm category (seven process alarms in Figure 5 below). For more information on alarms, see “Managing Alarms” on page 35.


Figure 5 Sensi+ Application Top Bar



Sidebar

The application sidebar provides access to most of the Sensi+ gas analyzer operational functions and options.


Figure 6 Sensi+ Sidebar (logged in as administrator)



Bottom Bar

The application bottom bar provides access to notifications, user documentation, login/logout functions, as well as shortcuts to Wi-Fi, Ethernet ports and date and time configurations.

Figure 7 Sensi+ Application Bottom Bar (logged in as an administrator)



Main Panel

The main panel indicates the contaminants measured, the measurements themselves, each contaminant linear trend (see “Configuring Gas Parameters” on page 17), as well as the presence of process and NAMUR alarms (see “Introducing NAMUR and Process Alarm Conventions” on page 35).

NOTE: The x axis on the non-linear trend graphics represents a time span of up to one hour linearly distributed (see also Figure 83 on page A81 for more details).

Figure 8 Sensi+ Application Main Panel



Page intentionally left blank

Configuring Sensi+

The Sensi+ gas analyzer is designed to be a plug-and-play instrument. Its default configuration aims at covering most use cases. However, there are situations where you might need to modify this default configuration. This chapter explains how to modify this configuration, once you established a link with the gas analyzer (see “Connecting to the Analyzer” on page 2).

Changing Default Administrator Password



NOTICE

For cybersecurity reasons, it is considered a best practice to change passwords after initial analyzer installation, and regularly thereafter. Not doing so could expose your entire network to cyberattacks.

With Sensi+, parameters, functions and interface items are made available depending on the username used to access the system.

Upon connecting with the system for the first time, you are presented with the basic Operator remote software interface.


To change the default administrator password:

- 1 Click the Login/Logout icon in the bottom bar (see Figure 7 on page 9).
- 2 In the **Login** dialog box that appears (see Figure 9 on page 11), enter the default administrator username and password and click **Login** at the bottom right of the dialog box.

If the original username and password were not changed as required during commissioning of the analyzer, the default administrator username and password are still:


- Username **admin**
- Password **Sens1plus!**

Figure 9 Entering the default Username and Password



- 3** Once logged in as an administrator, click **Users** in the Sensi+ application sidebar (see “Sidebar” on page 8). The **Users** panel appears to the right.

Figure 10 Users Panel



- 4** On the **Users** panel, in the **User** list below, click the user named **Administrator**.

Its information is displayed in the panel to the right.

- 5** If necessary, in the **Administrator** panel, change the **Full name** for something more meaningful.

NOTE: The user name entered when creating a new user **cannot** be changed.

- 6** In the **Change Password** text field, enter a new password (to make sure that the password is correct, you can reveal it by clicking the eye icon to the right of the text field).

- 7** In the **Confirm Password** text field, enter the same password as the one entered in the **Change password** text field.

The **Confirm Password** text field is highlighted in red until both passwords match perfectly.

- 8** Click **Apply** at the bottom of the User panel.


The administrator password is now changed.

Changing Analyzer Date and Time

Analyzer date and time should have been set to the analyzer's physical location date and time at commissioning. Normally, date and time do not need to be changed unless 1) the electronics containing the clock chip have been changed, or 2) the clock has drifted over a long period of time (~5 years).

When launching the analyzer remote interface, the analyzer's location date and time should appear in the bottom bar right corner, next to the ABB logo.

Figure 11 Sensi+ Application Bottom Bar




If the connecting computer time zone does not match the analyzer's time zone, a circled **i** appears next to the clock, as shown in Figure 11.

NOTE: Time zones can differ with no ill effect on data collection.

To synchronize the gas analyzer time zone with the user's computer time zone:

- 1 In the Sensi+ application sidebar, select **Settings > Configuration > General**.
- 2 At the bottom of the **General** panel, click **Synchronize Time Zone**. The analyzer time synchronizes with the connected PC time zone (date and time).

Figure 12 Setting Proper Date and Time Zone



NOTE: You can also click the circled **i** to synchronize date and time.


Naming Your Analyzer

If your Sensi+ is part of a fleet of instruments managed through a network, it is a good idea to assign each instrument on the network a meaningful and easily recognizable name.

To assign a name to your Sensi+:

- 1 In the Sensi+ application sidebar, select **Settings > Configuration > General**.

Figure 13 Configuring Sensi+ general parameters



- 2 In the **Instrument Name** text field, assign a name to the analyzer.
- 3 Click **Apply**. The name will appear on the local graphical user interface (GUI) (see Figure 82 on page A80).


Configuring Gas Measurement Units

Each gas measurement made by Sensi+ (H_2S , CO_2 , and H_2O) can be displayed with one of the following measurement units: ppmv, %vol, mg/m^3 or lbs/mmscf .

To configure each gas's measurement unit:

- 1 In the Sensi+ application sidebar, select **Settings > Configuration > General** (see Figure 14).
- 2 For each gas measured, select the measurement unit from a drop-down menu.

Figure 14 Selecting a measurement unit



- 3 Once the appropriate measurement units are selected, click **Apply**.

The selected measurement units will be used where appropriate throughout the application.


Configuring the Temperature Unit

The Sensi+ default temperature unit is the Celsius (°C), but you can change it to the Fahrenheit (°F) if necessary.

To do so:

- 1 In the Sensi+ application sidebar, select **Settings > Configuration > General**.
- 2 In the **Temperature Unit** drop-down menu, select **Fahrenheit**.

Figure 15 Configuring Sensi+ temperature units




- 3 Click **Apply**. Temperature units will now be Fahrenheit (°F) throughout the application.

Configuring Gas Parameters

Gas measurement range and threshold values are factory-set to simplify commissioning. However, these values can be modified if the initial configuration does not correspond to your current situation. The following pages explain how to perform these modifications.

Below is a visual representation of the various components of the gas parameters:

Figure 16 Illustration of The Various Components of Gas Process Parameters



NOTICE

When modifying display range and alarm threshold values, they must follow this logical relation:

- **Min Display Range < High Alarm Threshold**
- **High Alarm Threshold ≤ High High Alarm Threshold**
- **High High Alarm Threshold < Max Display Range**

The display range thresholds (maximum and minimum) can be modified as explained in “Configuring the Display Range” on page 18).

The alarm thresholds (High and High High) can be modified as explained in “Configuring Alarm Thresholds” on page 20).


The **linear range** of measurements is where minimal detectable changes, accuracy and repeatability are guaranteed as per the instrument specifications (“Measurement Specifications” on page E109).

The **trending range** starts as defined in the instrument specifications. It cannot be modified and is not user-configurable. Values in this range are measured but they are not as accurate as those in the linear range. As such, they are preceded by the symbol \approx . Values turn gray with a diagonal stroke when they become absolutely invalid (NAMUR alarm error, or not in instrument measurement range).

Configuring the Display Range

Display range values help visualize the recorded data shown in the **Measurements** panel. The values displayed are in direct linear relation with the 4–20 mA values defined during commissioning of the analyzer. Refer to the Sensi+ Installation and Commissioning Guide for more information.

Figure 17 Display Range in Measurements Panel




NOTE: Sensi+ keeps displaying measured values even if they go above the defined maximum display range or below the defined minimum display range. For example, in Figure 17 above, the maximum display range for CO₂ is 10%, but a value of 10,6% is displayed nevertheless.

To set the value display range:


- 1 From the Sensi+ application sidebar, click **Settings > Configuration > Gas Parameters**.
- 2 Under the **Name** column, select the gas whose display range you want to set (see Figure 18).

Figure 18 Setting H₂S gas parameters



3 Enter the appropriate values in the **Min Display Range** and **Max Display Range** text fields (see below).

Figure 19 Setting the display range



NOTE: Units of measurement can be changed as necessary (see “Configuring Gas Measurement Units” on page 15). Units of measurements are for each gas.

4 Click **Apply** at the bottom of the panel. The display range is set. You can repeat this procedure for the remaining gases.

NOTE: The **Min Display Range** value cannot be below 0 and the **Max Display Range** value cannot be above the maximum trending range (see “Measurement Specifications” on page E109).

Configuring Alarm Thresholds


Alarm thresholds help highlight potentially problematic levels of a contaminant in the gas. These thresholds are displayed on the **Measurements** panel.

The **High Alarm** threshold is a warning that indicates that attention should be given to a rising level of contaminant. It is indicated by the amber color in the **Measurements** panel (see H₂S in Figure 20)¹.

The **High High Alarm** threshold is the actual alarm level where contamination requires actions to be taken. When a High High alarm is registered for any of the measured contaminants, the associated digital output (DO) is triggered and values start appearing in red in the **Measurements** panel (see CO₂ gas in Figure 20). The trigger is often associated with closing the block valve to the pipeline, but it can be any action deemed necessary at the time of installation.

For more information on DOs, see “Configuring Output Connectors” on page 26. For more information on alarm colors and meanings, see Figure 16 on page 17 and “Introducing NAMUR and Process Alarm Conventions” on page 35.

Figure 20 High and High High Alarm Thresholds




To set the alarm thresholds:

- 1 From the Sensi+ application sidebar, click **Settings** > **Configuration** > **Gas Parameters**.
- 2 Under the **Name** column, select the gas whose alarm thresholds you want to set.


¹ A delay can be set before the H₂S contaminant High High alarm is raised. For more information, see “Changing the H₂S High High Alarm Delay” on page 22. There is no delay for the other contaminants.

Figure 21 Setting H₂S alarm thresholds



3 Enter the appropriate values in the **High Alarm Threshold** and **High High Alarm Threshold** text fields.

Figure 22 Setting alarm thresholds



NOTE: The unit of measurement used can be changed as necessary (see “Configuring Gas Measurement Units” on page 15). Units of measurements are for each gas.

4 Click **Apply** at the bottom of the panel.

Alarm thresholds are set. You can repeat this procedure for the remaining gases.

Modifying Zero Offsets and Span Gains

Zero offset and span gain values should **ONLY** be modified by trained and qualified service personnel. A reminder of the basics of modifying these values is provided in “Calculating Zero Offsets and Span Gains” on page D107

NOTE: Entering improper values could render analyzer measurements inaccurate and affect the efficiency of the entire system at generating meaningful warnings and alarms.

Changing the H₂S High High Alarm Delay


The H₂S high high alarm delay is the delay between the moment the H₂S high high threshold is reached and the moment it is reported (see “Configuring Alarm Thresholds” on page 20). This value should **ONLY** be modified by trained and qualified service personnel.

The default delay is six seconds. It ensures that at least three consecutive values are measured above the **Alarm High High** threshold before an alarm is raised.

To change this delay:

- 1 In the Sensi+ application sidebar, select **Settings > Configuration > General**.

Figure 23 Configuring Sensi+ H₂S High High alarm delay



- 2 In the **H₂S High High Alarm Delay** field, modify the number of seconds as necessary.
- 3 Click **Apply**.

From now on, the set delay will start to count down after recording the first value above the High High threshold. If more values are measured above that threshold during the countdown, the analyzer will raise a High High Alarm and trigger the associated digital output (for more information, see “Configuring Alarm Thresholds” on page 20 and “Configuring Output Connectors” on page 26). The trigger is often associated with closing the block valve to the pipeline but it can be any action deemed necessary at the time of installation.

Configuring Internal Connectors

In Sensi+ gas analyzers, internal connectors are preconfigured, and very few modifications can be performed. Modifications can be performed on the Ethernet ports, the Wi-Fi connection and the analog output state. These modifications are explained in the following pages.



MODBUS PROTOCOL DISCLAIMER

The Modbus® protocol is an unsecured protocol and, as such, the intended application of this system should be assessed to ensure that these protocols are suitable before implementation. To prevent any unauthorized accesses, always ensure that physical access to the analyzer and network are properly secured. For cybersecurity reasons, ABB decided not to password protect the Modbus communication protocol in Sensi+ series analyzers.

The Sensi+ (GLA533) analyzer requires access to the following TCP ports on the intranet:

- Modbus 502
- HTTPS Web Service 443

Details of the Modbus protocol are provided in “Modbus Table” on page C89.

Modifying the Client Ethernet Port Configuration


The Client Ethernet port, accessible during installation and commissioning (see the Sensi+ Installation and Commissioning Guide) is configured to be a DHCP client. As such, a DHCP host will automatically attribute an IP address to the analyzer upon connection to the network.

However, it is possible to configure the Client Ethernet port with a fixed IP address.

To modify the Client Ethernet port:


- 1 In the Sensi+ application sidebar, select **Settings > Configuration > Physical Interfaces > Client Ethernet.**

Figure 24 Configuring Sensi+ Client Ethernet port



- 2** In the **Client Ethernet** panel, click the blue **DHCP** toggle button. This hides the analyzer from the DHCP host and provides specific network connection text fields, as shown in Figure 25.

Figure 25 Configuring Sensi+ Client Ethernet port IP address



- 3** Enter the appropriate IP address information relevant to your network in the available fields
(IP Address, IP Mask, Gateway)

- 4** Click **Apply**.

The Client Ethernet port becomes visible again on your network, based on the information that you just entered.

NOTE: If necessary, you can also modify the port user label by changing the text in the **User Label** text field.


Modifying the Service Ethernet Port Configuration

The Sensi+ Service Ethernet port is configured with a fixed IP address (**10.0.0.1**). This address cannot be modified. However, you can modify its user label.

To modify the Service Ethernet port user label:

- 1 In the Sensi+ application sidebar, select **Settings > Configuration > Physical Interfaces > Service Ethernet**.

Figure 26 Configuring Sensi+ Service Ethernet Port user label



- 2 Change the text in the **User Label** text field.
- 3 Click **Apply**.

The Service Ethernet port user label is modified.

Configuring Output Connectors

In Sensi+, parameters sent through the output connectors (analog and digital) cannot be modified. The proper connections inside the instrument should have been performed during commissioning (for more information, see Table 1 on page 27 and refer to the Sensi+ Installation and Commissioning Guide).

However, since Sensi+ analog connectors are compatible with active or passive modes, you can configure this parameter in the Web remote interface. **By default, analog connectors are set to passive mode.**



NOTICE

DO NOT change from passive to active mode without first consulting with the personnel who performed the initial installation. Doing so without proper authorization from qualified personnel could damage the analyzer.

To set analog connectors in active mode:

- 1 In the Sensi+ application sidebar, select **Settings > Configuration > Physical Interfaces > I/O Boards**.
- 2 Next to the **AOs State** drop-down menu, select **Active** (see Figure 27).
- 3 Click **Apply**.
- 4 Reboot Sensi+ (see “Rebooting the Analyzer” on page 65).

Figure 27 Configuring Sensi+ active mode for analog outputs (AOs)




Table 1 Output Connectors Factory Set States

Connector	State Description
Digital	D01 H ₂ S High High Alarm
	D02 H ₂ S Failed
	D03 CO ₂ High High Alarm
	D04 CO ₂ Failed
	D05 H ₂ O High High Alarm
	D06 H ₂ O Failed
	D07 Reserved
	D08 Reserved
Analog	A01 H ₂ S
	A02 CO ₂
	A03 H ₂ O
	A04 Reserved



NOTICE

When Sensi+ stops being in a state to measure a specific gas within specifications, this gas' **Failed** digital output value will be set to its fail state (open; see "Digital Output Logic and Wiring" on page B87). This change of state can be caused by:

- Specific High NAMUR alarms
- Specific Function Check NAMUR alarms (e.g., warm-up sequence, validation mode,...)

While in this **Failed** state, the gas' High High alarms should be ignored as the measured concentrations and associated High High alarm digital outputs could be erroneous.

For more information on alarms, see "Introducing NAMUR and Process Alarm Conventions" on page 35.

Configuring Wi-Fi Connections (optional)

On Sensi+, the Wi-Fi connection is optional. If your Sensi+ comes with this option, an antenna will be visible on the instrument housing. In such a situation, Wi-Fi connectivity is enabled by default, but few parameters can be modified. The analyzer's country of operation, IP address (**10.0.1.1**) and SSID (**GLA533-CPU_Serial_Number**) cannot be modified.

Changing the Wi-Fi Password

By default, the Sensi+ password is **Sens1plusWF!**. It should have been changed upon commissioning of Sensi+.


NOTE: If you forgot the Wi-Fi password, only users with administrator or maintenance privileges can recover that password from the analyzer Wi-Fi configuration parameters.

To change it again:

- 1 In the Sensi+ application sidebar, select **Settings > Configuration**.
- 2 In the **Configuration** panel displayed, select **Physical Interfaces > Wi-Fi** (see Figure 29 on page 29).
- 3 In the **Password** text field, enter a new password.

To ensure that you enter the correct password, click the “eye” icon on the right-hand side of the text field to reveal the exact content of the password (see Figure 28).

Figure 28 Revealing the current password



- 4 Click **Apply** at the bottom of the panel.


The new password is now in effect, and will be valid on the **next** connection.

Disabling/Enabling Wi-Fi connections

To disable (or re-enable) the Wi-Fi connection:

- 1 In the Sensi+ application sidebar, select **Settings > Configuration**.
- 2 In the **Configuration** panel displayed, select **Physical Interfaces > Wi-Fi**

Figure 29 Configuring Sensi+ Wi-Fi connection



- 3 Click the toggle button next to **Enabled**. The toggle button turns black.
- 4 Click **Apply** at the bottom of the panel.

The Wi-Fi connection becomes inactive.

If you were currently connected via Wi-Fi, you lose the connection immediately.

Configuring User Profiles

Different types of users have access to different types of functions in the Sensi+ Web remote interface.



NOTICE


Only users logged in as administrators can create, modify, or delete user profiles.

Creating a User Profile

To create a user profile:

- 1 In the Sensi+ application sidebar, select **Users**.
- 2 In the **Users** panel, click the + sign next to the **User** list title. The **Create user** panel appears to the right.

Figure 30 Creating a user profile



- 3 Enter the appropriate information in each field as detailed below:
 - **User Name:** the name with which the system will recognize the user (between 3 and 30 characters). It is the name to enter when logging into the system. Once created, this user name cannot be changed. There cannot be two identical user names
 - **Full name:** the real name of the user whose profile you are creating.
 - **Account Enabled:** by default, a new user account is disabled. Only administrators can enable and disable user accounts (e.g., when an employee leaves). To enable an account, click the **Account Enabled** toggle button. The toggle button turns blue to indicate activation.
 - **Account Unlocked:** by default, a new user account is unlocked. A user account can be locked by the system (e.g., after reaching the maximum number of failed password input). Only administrators can unlock user accounts. To unlock it, click the **Account Unlocked** toggle button. The toggle button turns blue to indicate activation.
 - **User Role:** each role provides specific access rights to its user. Three roles exist in the gas analyzer: Operator, Maintenance and Administrator.

Table 2 Access Rights for Each User Role

	Operator	Maintenance	Administrator
Measurements panel	No restrictions	No restrictions	No restrictions
Alarms and Events panels	Export, Filter	Acknowledge, annotate, export, filter	Acknowledge, annotate, export, filter
Configuration panel	View	View and modify	View and modify
Reports panel	No restrictions	No restrictions	No restrictions
Users panel	Not visible	Not visible	View and modify
Maintenance panel	View analyzer local display	<ul style="list-style-type: none">• View analyzer local display• View and modify Validation panel• View and modify Advanced panel• View and modify Service panel	<ul style="list-style-type: none">• View analyzer local display• View and modify Validation panel• View and modify Analyzer panel• View and modify Advanced panel• View and modify Service panel
Help panel	No restrictions	No restrictions	No restrictions

– **Preferred Language:** only English is available.

– **Initial Password:** enter a password. When you enter a password, the **Confirm Password** field becomes highlighted in red.

To ensure that you enter the correct password, click the “eye” icon on the right-hand side of the text field to reveal the exact content of the password (see Figure 28 on page 28).

– **Confirm Password** (highlighted in red once a password is entered in the field **Change Password**): reenter the same password as the one you entered in the **Change Password** field. When you reenter the password correctly, the red highlight disappears.

To ensure that you enter the correct password, click the “eye” icon on the right-hand side of the text field to reveal the exact content of the password (see Figure 28 on page 28).



PASSWORD MANAGEMENT RULES

- Passwords must be between 3 and 12 (users) or 16 (administrators) characters long.
- Passwords can contain lowercase and uppercase letters, special characters and numbers.
- Administrator passwords must contain characters from at least two categories.
- Any user is locked out of the system after the 9th try at entering a password.
Administrators are locked out for 15 minutes and users, 5 minutes.
- Administrators can unlock any other user and reset all other passwords.
- **If all passwords are forgotten (including the last administrator password), the analyzer will be completely locked and require a factory reset, thus erasing the complete content of all internal databases.**


- 4 Click **Create**. The new user profile appears in the **User** list and this user can now enter the Web remote interface according to its role.

Modifying a User Profile

To modify a user profile:

- 1 In the Sensi+ application sidebar, select **Users**.
- 2 In the **Users** panel displayed, select the user whose profile you want to modify.

Figure 31 Editing a user profile



- 3 Modify the information as necessary.

NOTE: The user name **cannot** be modified.


- 4 Click **Apply**. The modified information becomes active.

Deleting a User Profile

To delete a user profile:

- 1 In the Sensi+ application sidebar, select **Users**.
- 2 In the **Users** panel displayed, select the user profile that you want to delete.
- 3 Click the trash can icon next to the user name at the top of the panel.
- 4 In the confirmation dialog box that appears, click **Delete user**. The user profile is deleted and the person using this profile will no longer have access to the associated functions.

Figure 32 Deleting a user profile



NOTICE

It is not possible to delete the last user with an Administrator **role**.

However, it is possible to delete the **default** Administrator if another user with Administrator **role** is still available.

Page intentionally left blank

Managing Alarms

Alarms can be raised when abnormal situations occur in a monitored process (process alarms) or the analyzer (NAMUR alarms). The following pages explain how to manage these alarms.

Introducing NAMUR and Process Alarm Conventions

The analyzer can raise two alarm types: process and NAMUR. Process alarms indicate abnormal situations within the process (the monitored substances), whereas NAMUR alarms relate to abnormal situations within the analyzer itself.

Table 3 Process Alarms

Alarm	Icon	Meaning
High Alarm (red)		Indicates High High alarms. Current measured value exceeds the specified alarm range.
Warning Alarm (amber)		Indicates High alarms. Current measured value exceeds the specified warning range.
Information (cyan)		Notification Only occurs on uncertain gas quality.
None (green)		No high alarm, warning or information related to the process.

For additional information on configuring alarm thresholds, see “Configuring Alarm Thresholds” on page 20. See also Figure 16 on page 17 for a visual representation of these various thresholds and alarms.

Table 4 NAMUR Alarms


Alarm	Icon	Meaning
Failure		HIGH SEVERITY Analyzer has an invalid signal due to hardware malfunction (temperature/pressure sensor, electronic board, pump, variable valve, pressure leak, processing error, etc.)
Out of specification		MEDIUM SEVERITY Analyzer is operating beyond its setup, permissible range or specification (temperature or pressure range, etc.).
Check function		LOW SEVERITY Analyzer has a temporarily invalid signal, e.g., during validation, stream or pump switching, test modes (test I/Os), temporary data processing overflow, etc.
Maintenance required		LOW SEVERITY Analyzer has a valid signal, but function may drop or cease to function soon, such as for preventive pump replacement notifications, preventive laser strength or cell cleanliness notification.
Diagnosis active		NO ERROR Analyzer is operating as expected

Displaying Alarms

General alarm notifications appear in the top right corner of the Sensi+ application (see Figure 33).

To display specific alarms (process or NAMUR), click the appropriate icon. The relevant **Alarms** table appears, and the **Filters** panel appears as well to confirm which alarms are displayed.

Figure 33 Process Alarms and Filters panel



You can also click **Alarms** from the Sensi+ application sidebar. When displaying alarms this way, they are not automatically filtered by alarm type (process vs. NAMUR).

NOTE: Alarms are displayed **only** if they are still active and/or need to be acknowledged.

Sorting Alarms

In the **Alarms** panel, you can sort alarms in chronological or reverse chronological order. By default, alarms are sorted in reverse chronological order (most recent first).

To sort alarms:

- From the Sensi+ application, click **Alarms** in the sidebar.

Figure 34 Alarms Panel

The screenshot shows the Sensi+ application interface with the 'Alarms' panel selected. The main area displays a table of alarms with columns: Ack, Priority, Type, Time, Message ID, and Description. The 'Time' column has a downward-pointing arrow icon, indicating it is used for sorting. The top right corner of the panel contains two icons: a red hexagon with a white exclamation mark labeled 'Exporting reports icon' and a red circle with a white minus sign labeled 'Advanced Filter icon'. The bottom of the screen shows the operating system's taskbar with various icons and the date/time 'Sep 2, 2022 11:50 AM'.

Ack	Priority	Type	Time	Message ID	Description
	800	critical	9/2/2022, 11:42:57 AM	91918	S1_VALVE_REQ_CLOSE
	700	critical	9/2/2022, 11:42:51 AM	0	H2S: PROCESS_ALARM_HIGH
	800	critical	9/2/2022, 10:52:57 AM	91046	S1_VALVE_REQ_CLOSE
	800	critical	9/2/2022, 10:02:57 AM	90577	S1_VALVE_REQ_CLOSE
	800	critical	9/2/2022, 9:12:57 AM	90104	S1_VALVE_REQ_CLOSE
	800	critical	9/2/2022, 8:22:57 AM	89627	S1_VALVE_REQ_CLOSE
	800	critical	9/2/2022, 7:32:57 AM	89154	S1_VALVE_REQ_CLOSE
	800	critical	9/2/2022, 6:42:57 AM	88680	S1_VALVE_REQ_CLOSE
	800	critical	9/2/2022, 5:52:57 AM	88210	S1_VALVE_REQ_CLOSE
	800	critical	9/2/2022, 5:02:57 AM	87742	S1_VALVE_REQ_CLOSE
	800	critical	9/2/2022, 4:12:57 AM	87368	S1_VALVE_REQ_CLOSE
	800	critical	9/2/2022, 3:22:57 AM	86790	S1_VALVE_REQ_CLOSE
	800	critical	9/2/2022, 2:32:57 AM	86313	S1_VALVE_REQ_CLOSE
	800	critical	9/2/2022, 1:42:57 AM	85835	S1_VALVE_REQ_CLOSE
	800	critical	9/2/2022, 12:52:57 AM	85334	S1_VALVE_REQ_CLOSE
	800	critical	9/2/2022, 12:02:57 AM	84860	S1_VALVE_REQ_CLOSE

- In the **Time** column, click ▼ to sort alarms starting with the latest, and ▲ to sort them starting from the earliest.

Acknowledging Alarms

From the **Alarms** table, you can acknowledge individual alarms, more than one alarm or all alarms at once. The following pages explain these procedures.

NOTE: Alarms displaying a dash in the **Ack** column cannot be acknowledged and removed from the **Alarms** table.

Acknowledging One Alarm

To acknowledge just one alarm:


- 1 From the **Alarms** table, underneath the **Ack** column, check the box next to the alarm that you want to acknowledge (see Figure 35).

Figure 35 Checking a box to acknowledge one alarm

	Ack	Priority	Type	
	<input type="checkbox"/>	700	●	6/
	<input type="checkbox"/>	800	●	6/
>	<input type="checkbox"/>	800	●	6/
>	<input checked="" type="checkbox"/>	800	●	6/
	<input type="checkbox"/>	800	●	6/
	<input type="checkbox"/>	800	●	6/

- 2 As soon as you check the box in the **Ack** column, a **Comment** dialog box appears (see Figure 36) where you can enter a comment as to why you acknowledge the selected alarm.

Figure 36 Commenting on alarm acknowledgment



- 3 Once the comment is entered, click **Acknowledge**.

The selected alarm is acknowledged, **but** it remains in the **Alarms** table if the condition that caused the alarm is still present. The alarm will disappear from the table once the condition that caused it has been fixed.

If you need to review the alarm once it has been acknowledged, go to the **Events** table (for more information on managing events, see “Managing Events” on page 49).

Acknowledging More Than One Alarm

To acknowledge more than one alarm:


- From the **Alarms** table, in the leftmost column (left of the **Ack** column), check the boxes next to the alarms that you want to acknowledge (see Figure 37).

Figure 37 Checking More Than One Box Next to Alarms to Acknowledge

-	Ack ▾	Priority ▾	Type ▾	Time ▾
<input type="checkbox"/>	—	400	▲	6/10/2022, 11:10:15 AM
<input type="checkbox"/>	—	700	●	6/10/2022, 11:10:13 AM
<input checked="" type="checkbox"/>	□	800	●	6/10/2022, 10:28:21 AM
<input type="checkbox"/>	□	800	●	6/10/2022, 9:38:21 AM
<input checked="" type="checkbox"/>	□	800	●	6/10/2022, 7:58:21 AM
<input type="checkbox"/>	□	800	●	6/10/2022, 7:08:21 AM
<input checked="" type="checkbox"/>	□	800	●	6/10/2022, 6:18:21 AM
<input type="checkbox"/>	□	800	●	6/10/2022, 5:28:21 AM
<input type="checkbox"/>	□	800	●	6/10/2022, 4:38:21 AM

- Click the checkmark at the top of the column (see Figure 37). As soon as you click the checkmark, a **Comment** dialog box appears (see Figure 38) where you can enter a comment as to why you acknowledge the selected alarms.

Figure 38 Commenting on alarms acknowledgment



- Once the comment is entered, click **Acknowledge**.

The selected alarms are acknowledged, **but** they remain in the **Alarms** table if the conditions that caused them are still present. The alarms will disappear from the table once the conditions that caused them have been fixed.

If you need to review alarms once they have been acknowledged, go to the **Events** table (for more information on managing events, see “Managing Events” on page 49).

Acknowledging All Alarms at Once

To acknowledge all alarms at once:

- From the **Alarms** table, in the leftmost column (left of the **Ack** column), check the box in the column title. This selects all current alarms (see Figure 39).

Figure 39 Checking all boxes next to alarms to acknowledge

	Ack	Priority	Type	Date
	<input checked="" type="checkbox"/>	700	●	6/10/2023
	<input checked="" type="checkbox"/>	800	●	6/10/2023
	<input checked="" type="checkbox"/>	800	●	6/10/2023
	<input checked="" type="checkbox"/>	800	●	6/10/2023
	<input checked="" type="checkbox"/>	800	●	6/10/2023
	<input checked="" type="checkbox"/>	800	●	6/10/2023
	<input checked="" type="checkbox"/>	800	●	6/10/2023

- Click the checkmark at the top of the column (see Figure 37 on page 40). As soon as you click the checkmark, a **Comment** dialog box appears (see Figure 38) where you can enter a comment as to why you acknowledge the selected alarms.
- Once the comment is entered, click **Acknowledge**.

The selected alarms are acknowledged, **but** they remain in the **Alarms** table if the conditions that caused them are still present. The alarms will disappear from the table once the conditions that caused them have been fixed.

If you need to review alarms once they have been acknowledged, go to the **Events** table (for more information on managing events, see “Managing Events” on page 49).

Filtering Alarms

In the **Alarms** panel, you can filter the content of the alarm table by status, priority, type and/or time period. You can filter the content from the general **Filters** panel or from a specific column in the **Alarms** table. The following pages explain these filtering options.


Filtering by Alarm Status

The status of an alarm is either **Acknowledged** or **Not Acknowledged**. You can filter out all alarms that were acknowledged to keep only the alarms still needing acknowledgment.

To do so:

- From the **Alarms** table, click the funnel icon next to the **Ack** column title. The **Status** filter is displayed.

Figure 40 Status Filter



- In the **Status** filter, select **Not acknowledged**, then click outside the filter. The filter disappears and only alarms to be acknowledged remain in the **Alarms** table.


NOTE: When a filter is applied to a column, the funnel icon turns blue.

You can also filter by alarm status from the **Filters** panel.

To do so:

- From the **Alarms** panel, click the Advanced Filter icon (see Figure 34 on page 38). The **Filters** panel appears below the **Alarms** panel.

Figure 41 Filters Panel by Status



- Under **Status**, select **Not acknowledged**. All acknowledged alarms are immediately removed from the **Alarms** table.
For more information on acknowledging alarms, see “Acknowledging Alarms” on page 39
- Close the **Filters** panel by clicking the Advanced Filter icon (see Figure 34 on page 38).

Filtering by Priority

In Sensi+, alarms are assigned a priority, and a level within that priority as shown in the table below.

Table 5 Alarm Priorities

Priority	Severity Level
Information	0 to 99
Notification	100 to 399
Warning	400 to 699
Alarm	700 to 999

You can filter alarms by priority and/or by severity level.

To do so:

- From the **Alarms** table, click the funnel icon next to the **Priority** column. The **Priority** filter is displayed.

Figure 42 Priority Filter



- In the **Priority** filter, select the required priority from the drop-down menu. All other priorities are removed from the current **Alarms** table.
- If necessary, you can fine-tune the filter further by specifying a range of security levels in the text boxes located underneath. The modified range is immediately updated as you change the range of the severity level.
- Click outside the filter. The filter disappears and only alarms with the specified priorities remain in the **Alarms** table.


NOTE: When a filter is applied to a column, the funnel icon turns blue.

You can also filter by alarm priority from the **Filters** panel.

To do so:

- From the **Alarms** panel, click the Advanced Filter icon (see Figure 34 on page 38). The **Filters** panel appears below the **Alarms** panel.

Figure 43 Filters Panel by Priority



- Under **Priority**, select the required priority from the drop-down menu. All other priorities are removed from the current **Alarms** table.
- If necessary, you can fine-tune the filter further by specifying a range of security levels in the text boxes located underneath. The modified range is immediately updated as you change the range of the severity level.
- Close the **Filters** panel by clicking the Advanced Filter icon (see Figure 34 on page 38).

Filtering by Alarm Type

The analyzer can raise two alarm types: process and NAMUR. Process alarms indicate abnormal situations within the process (the monitored substances), whereas NAMUR alarms relate to abnormal situations within the analyzer itself.

Quick Filter

You can quickly filter and display alarms by type. For example, to quickly filter for all process alarms, click the Process alarms icon in the Sensi+ top bar (see “Sensi+ Application Top Bar” on page 8). The **Alarms** panel opens, as well as the **Filters** panel, which indicates that all process alarms are displayed.

Figure 44 Filters Panel - Only Process Alarms



You can proceed in the same fashion to quickly filter by NAMUR alarms by clicking the NAMUR alarm icon in the Sensi+ top bar (see “Sensi+ Application Top Bar” on page 8). The **Alarms** panel opens, as well as the **Filters** panel, which indicates that all NAMUR alarms are displayed.


From the Alarms Type column

You can also filter alarms from the **Type** column in the **Alarms** table.

To do so:

- 1 From the **Alarms** table, click the funnel icon next to the **Type** column title. The **Type** filter is displayed.

Figure 45 Type Filter



- 2 In the **Type** filter, uncheck the boxes next to the alarm types that you want hide in the **Alarms** table, then click outside the filter. The filter disappears and only “checked” alarms remain in the **Alarms** table.

NOTE: When a filter is applied to a column, the funnel icon turns blue.


From the Filters panel

You can also filter by alarm type from the **Filters** panel.

To do so:

- 1 From the **Alarms** panel, click the Advanced Filter icon (see Figure 34 on page 38). The **Filters** panel appears below the **Alarms** panel.

Figure 46 Filters Panel by Type



- 2 Under **Process** and/or **NAMUR**, uncheck the boxes next to the alarm types that you want hide in **Alarms** table. The unchecked alarms are automatically hidden and only “checked” alarms remain in the **Alarms** table.
- 3 Close the **Filters** panel by clicking the Advanced Filter icon (see Figure 34 on page 38).


Filtering by Time Period

In the **Alarms** table, you can choose to display only alarms that happened during a specific time period.

To do so:

- From the **Alarms** table, click the funnel icon next to the **Time** column title. The **Period** filter is displayed.

Figure 47 Period Filter




- In the **Period** filter, you can either specify a relative time period (i.e., last 7 days, last 2 hours, etc.) or an absolute time period (from date and time x to date and time y).

To set a relative time period:

- Select the proper unit of time (days, hours, minutes, seconds).
- Enter the required number for that time period.


Figure 48 Setting a relative time period filter



To set an absolute time period:

- In the **From** date field, click the calendar icon on the right-hand side of the field (see Figure 49 on page 47).

Figure 49 Setting an absolute time period filter



- b On the left-hand side of the filter, select the start **date** of the time period.
- c On the right-hand side of the filter, select a start **time** for the time period.
- d Repeat steps b and c for the end time period in the **To** date field.

The **Alarms** table is automatically updated.

- 3 Click outside the filter. The filter disappears and only alarms that occurred during the specified time period remain in the **Alarms** table.

NOTE: When a filter is applied to a column, the funnel icon turns blue.

Exporting Alarms

Alarms cannot be exported independently, but they can be exported as part of an events report (for more information on exporting events, see “Managing Reports” on page 59).

Page intentionally left blank

CHAPTER 5

Managing Events

Events happen inside the analyzer: configuration changes, alarm status changes (warning to alarm, warning to normal, etc.), system errors and reboots, etc. All these events are recorded by the Sensi+ gas analyzer. The following pages explain how to manage these events.

Displaying Events

To display analyzer events, click **Events** from the Sensi+ application sidebar. By default, events are sorted in reverse chronological order (most recent first), and filtered to display only events that occurred during the last week.


Sorting Events

In the **Events** panel, you can sort events in chronological or reverse chronological order. By default, events are sorted in reverse chronological order (most recent first).

To sort events:

- 1** From the Sensi+ application sidebar, click **Events**.

Figure 50 Events Panel



- 2** In the **Time** column, click ▼ to sort alarms starting with the latest, and ▲ to sort them starting from the earliest.

Acknowledging Events

It is possible to acknowledge events for which actions have been taken. You can either acknowledge each event individually or all at once and you can do so while being connected remotely or when you are on site with a computer on hand.

From the **Events** table, you can acknowledge individual events, more than one event or all events at once. The following pages explain these procedures.

NOTE: Events displaying a dash in the **Ack** column cannot be acknowledged.

Acknowledging One Event

To acknowledge just one event:


- 1 From the **Events** table, underneath the **Ack** column, check the box next to the event that you want to acknowledge (see Figure 51).

Figure 51 Checking a box to acknowledge one event

	Ack	Priority	Type	
	<input type="checkbox"/>	700	●	0
	<input type="checkbox"/>	700	●	0
	<input type="checkbox"/>	700	●	0
	<input checked="" type="checkbox"/>	800	●	0
	<input type="checkbox"/>	700	●	0
	<input type="checkbox"/>	700	●	0
	<input type="checkbox"/>	400	▲	0

- 2 As soon as you check the box in the **Ack** column, a **Comment** dialog box appears (see Figure 52) where you can enter a comment as to why you acknowledge the selected event.

Figure 52 Commenting on event acknowledgment



- 3 Once the comment is entered, click **Acknowledge**. The selected event is acknowledged and a checkmark appears in next to it in the **Ack** column.

Acknowledging More Than One Event

To acknowledge more than one event:


- From the **Events** table, in the leftmost column (left of the **Ack** column), check the boxes next to the events that you want to acknowledge (see Figure 53).

Figure 53 Checking boxes next to events to acknowledge

-	Ack	Priority	Type	Time
<input type="checkbox"/>	-	700	☒	6/14/2022, 11:45 AM
<input type="checkbox"/>	-	700	☒	6/14/2022, 11:45 AM
<input checked="" type="checkbox"/>	☒	800	☒	6/14/2022, 11:45 AM
<input type="checkbox"/>	-	700	☒	6/14/2022, 11:45 AM
<input type="checkbox"/>	-	700	☒	6/14/2022, 11:45 AM
<input type="checkbox"/>	-	400	⚠	6/14/2022, 11:45 AM
<input type="checkbox"/>	-	400	⚠	6/14/2022, 11:45 AM

- Click the checkmark at the top of the column (see Figure 53). As soon as click the checkmark, a **Comment** dialog box appears (see Figure 54) where you can enter a comment as to why you acknowledge the selected events.

Figure 54 Commenting on events acknowledgment




- Once the comment is entered, click **Acknowledge**. The selected events are acknowledged and a checkmark appears in next to them in the **Ack** column.

Acknowledging All Events at Once

To acknowledge all events at once:

- 1 From the **Events** table, in the leftmost column (left of the **Ack** column), check the box in the column title. This selects all current events (see Figure 55).

Figure 55 Checking boxes next to events to acknowledge



Events				
	Ack	Priority	Type	
	<input checked="" type="checkbox"/>	700	■	6/
	<input checked="" type="checkbox"/>	400	▲	6/
	<input checked="" type="checkbox"/>	700	■	6/
	<input checked="" type="checkbox"/>	400	▲	6/
	<input checked="" type="checkbox"/>	700	■	6/
	<input checked="" type="checkbox"/>	400	▲	6/

- 2 Click the checkmark at the top of the column (see Figure 55). As soon as click the checkmark, a **Comment** dialog box appears (see Figure 54) where you can enter a comment as to why you acknowledge the selected events.
- 3 Once the comment is entered, click **Acknowledge**. All events are acknowledged and a checkmark appears in next to them in the **Ack** column.

Filtering Events

In the **Events** panel, you can filter the content of the event table by status, priority and/or time period. You can filter the content from the general **Filters** panel or from a specific column in the **Events** table. The following pages explain these filtering options.


Filtering by Event Status

The status of an event is either **Acknowledged** or **Not Acknowledged**. You can filter out all events that were acknowledged to keep only the events still needing acknowledgment.

To do so:

- From the **Events** table, click the funnel icon next to the **Ack** column title. The **Status** filter is displayed.

Figure 56 Status Filter



- In the **Status** filter, select **Not acknowledged**, then click outside the filter. The filter disappears and only events to be acknowledged remain in the **Events** table.


NOTE: When a filter is applied to a column, the funnel icon turns blue.

You can also filter by event status from the **Filters** panel.

To do so:

- From the **Events** panel, click the Advanced Filter icon (see Figure 50 on page 49). The **Filters** panel appears below the **Events** panel.

Figure 57 Filters Panel by Status



- 2** Under **Status**, select **Not acknowledged**. All acknowledged events are immediately removed from the **Events** table.
For more information on acknowledging events, see “Acknowledging Events” on page 50.
- 3** Close the **Filters** panel by clicking the Advanced Filter icon (see Figure 50 on page 49).

Filtering by Priority

In Sensi+, events are assigned a priority, and a level within that priority, as shown in the table below.

—
Table 6 Event Priorities


Priority	Severity Level
Information	0 to 99
Notification	100 to 399
Warning	400 to 699
Alarm	700 to 999

You can filter events by priority and/or by severity level.

To do so:

- 1** From the **Events** table, click the funnel icon next to the **Priority** column. The **Priority** filter is displayed.

—
Figure 58 Priority Filter



- 2** In the **Priority** filter, select the required priority from the drop-down menu. All other priorities are removed from the current **Events** table.
- 3** If necessary, you can fine-tune the filter further by specifying a range of security levels in the text boxes located underneath. The modified range is immediately updated as you change the range of the severity level.
- 4** Click outside the filter. The filter disappears and only events with the specified priorities remain in the **Events** table.


NOTE: When a filter is applied to a column, the funnel icon turns blue.

You can also filter by event priority from the **Filters** panel.

To do so:

- From the **Events** panel, click the Advanced Filter icon (see Figure 34 on page 38). The **Filters** panel appears below the **Events** panel.

Figure 59 Filters Panel by Priority



- Under **Priority**, select the required priority from the drop-down menu. All other priorities are removed from the current **Events** table.
- If necessary, you can fine-tune the filter further by specifying a range of security levels in the text boxes located underneath. The modified range is immediately updated as you change the range of the severity level.
- Close the **Filters** panel by clicking the Advanced Filter icon (see Figure 50 on page 49).


Filtering by Time Period

In the **Events** table, you can choose display only events that happened during a specific time period.

To do so:

- From the **Events** table, click the funnel icon next to the **Time** column title. The **Period** filter is displayed.

Figure 60 Period Filter




- In the **Period** filter, you can either specify a relative time period (i.e., last 7 days, last 2 hours, etc.) (see or an absolute time period (from date and time x to date and time y).

To set a relative time period:

- Select the proper unit of time (days, hours, minutes, seconds).
- Enter the required number for that time period.


Figure 61 Setting a relative time period filter



To set an absolute time period:

- In the **From** date field, click the calendar icon on the right-hand side of the field (see Figure 62).

Figure 62 Setting an absolute time period filter



- On the left-hand side of the filter, select the start **date** of the time period.
- On the right-hand side of the filter, select a start **time** for the time period.
- Repeat steps **b** and **c** for the end time period in the **To** date field.

The **Alarms** table is automatically updated.

- Click outside the filter. The filter disappears and only alarms that occurred during the specified time period remain in the **Alarms** table.

NOTE: When a filter is applied to a column, the funnel icon turns blue.

Exporting Events

Events can be exported from the **Reports** panel. For more information on exporting events, see “Managing Reports” on page 59.

Page intentionally left blank

Managing Reports

With the Sensi+ Web remote interface, you can generate and download six types of reports:

- **Events:** content of the **Events** table (including alarms)
- **Results:** instrument data and measured gas concentrations
- **Results (compact):** instrument data and measured gas concentrations, in a more compact format
- **Health Monitoring:** instrument health monitoring data
- **Health Monitoring (compact):** instrument health monitoring data in a more compact format
- **Spectra:** all instrument spectra data acquired.

Compact reports focus on the main parameters and are recommended for Results and Health Monitoring exports


Generating Reports

NOTE: Report generation can take between a few seconds and a few minutes depending on the type and size of the report to generate. You can cancel ongoing report generation by clicking **Cancel**.

To generate any of these reports:

- 1 In the Sensi+ application sidebar, select **Reports**.
- 2 In the **Reports** panel, under the reports **Name** list, select the report that you want to generate (see Figure 63).

Figure 63 Selecting a report to generate



- 3 Click **Generate now**. The report file is generated¹ and the date and time of that report appear next to **Latest generation time**.

NOTE: If the web browser is disconnected from the instrument or the Web page refreshed, all ongoing report generation is canceled.

To view the report content, you will need to download the report as explained in the next section.

¹ In .tsv format, save for spectra files that are saved in .h5 format.


Downloading Reports

To download any of these reports:

- 1 In the Sensi+ application sidebar, select **Reports**.
- 2 In the **Reports** panel, under the report **Name** list, select the generated report that you want to download (to generate a report, see “Generating Reports” on page 59).

If there is no **Latest generation time** indicated, no report has been generated at this point. You will need to generate that report before downloading it, as explained in “Generating Reports” on page 59

Figure 64 Downloading an existing report



- 3 Click **Download latest**. A **Save As** dialog box appears¹ in which you can browse to a directory where you want to save the report file (.tsv file, or .h5 files for spectra data).

NOTE: .tsv files are tab-delimited text files. They can be opened in generic text applications like Microsoft® NotePad™ or in spreadsheet programs like Microsoft Excel®. .h5 files are destined to be opened in an ABB-specific software for troubleshooting purposes.

- 4 If necessary, you can also change the name of the report file. By default, the report is named as indicated in the **Reports** list (*Events.tsv*, *Results.tsv*, *CompactResults.tsv*, *HealthMonitoring.tsv*, *CompactHealthMonitoring.tsv*).
- 5 In the **Save As** dialog box, click **Save**. The report file is downloaded in the selected directory.

¹ Depending on the web browser used. Some web browsers save automatically to a specific folder, i.e., Downloads.

Page intentionally left blank

Troubleshooting and Maintenance

As usual with ABB products, reliability is of the essence. Troubleshooting might happen occasionally. Most of the time, service has to be performed by authorized ABB service personnel. If such situations arise, you will need to contact ABB after-sales service. When in contact with ABB service personnel, you might be asked to provide certain information about your system. The following pages provide relevant details.

Diagnosing Problems

Most problems that could happen within the Sensi+ gas analyzer will be recorded as events in the **Events** table. You will be informed of these problems either with alarms or by looking at the LEDs on the analyzer housing. The meaning of the various LEDs is explained below.

Table 7 Analyzer LED Behavior

Power	Process	NAMUR
 Solid YELLOW (power on; during software boot process; during software update with USB key)	 OFF (during boot and warmup process)	 OFF (during boot process)
 Solid GREEN (when powered up; software booted)	 OFF (during boot and warmup process)	 Blinking GREEN (during warmup; normal initialization phase)
 Solid GREEN (when powered up; software booted)	 Solid GREEN (when process values are valid; software booted, no process error)	 Solid GREEN (when powered up; software booted, no NAMUR error)

		
		
		Solid ORANGE (Warning [see page 35])
		Solid ORANGE (Check Function; temporarily invalid [see page 35])
		Solid RED (Alarm [see page 35])
		Solid RED (Alarm [see page 35])
		Solid BLUE (notifications)
		Solid BLUE (valid system data, but requires maintenance)

Resetting the Analyzer After Triggered Digital Output

The method to reset the analyzer once a digital output has been triggered depends on whether or not your system is equipped with a return loop.

If your system is equipped with a return loop:

- 1 Acknowledge the alarm (see “Acknowledging One Alarm” on page 39).
- 2 Fix the source of the contamination (or inform the gas provider that there is contamination that needs to be fixed).
- 3 Once the source of the contamination has been fixed, reopen the block valve.

If your system is not equipped with a return loop:

- 1 Acknowledge the alarm (see “Acknowledging One Alarm” on page 39).
- 2 Stop the gas input (by either shutting down the inlet valve or by asking your gas provider to shutdown its outlet valve).
- 3 Fix the source of the contamination (or inform the gas provider that there is contamination that needs to be fixed).
- 4 Once the source of the contamination has been fixed, reopen the block valve.

¹ Yellow NAMUR alarm also lights up during analyzer startup and when the analyzer is in validation mode.

Rebooting the Analyzer


After performing certain maintenance tasks, you might need to reboot the analyzer.

NOTE: You need Administrator access rights to reboot the analyzer.

To do so:


- 1 In the Sensi+ application sidebar, select **Maintenance > Analyzer Control**.
- 2 Click **Reboot instrument** (see Figure 65).

Figure 65 Rebooting the analyzer



- 3 In the confirmation dialog box that appears, click **Reboot**.

Figure 66 Confirming the Reboot



The instrument will shut down and restart, going through all the initialization process. All digital outputs (DOs) reset upon reboot. They will gradually return to their “ready” state until the reboot is complete. You can follow the reboot process by watching the LEDs behavior, as indicated in Table 7 on page 63.


Performing Analyzer Validation

Analyzer validation is typically performed at the end of commissioning to ensure that the system is working properly from the start.

To perform a validation:

- 1 Connect the computer and the analyzer (see “Connecting to the Analyzer” on page 2).
- 2 Log in to the analyzer as administrator (see “Logging Into the Analyzer” on page 4).
- 3 In the Sensi+ application sidebar, select **Maintenance > Validation** (see Figure 67).

Figure 67 Validation panel



- 4 From the **Validation** panel, click the **Validation Mode** toggle button, then click **Apply**.
This raises a NAMUR orange alarm (see “Introducing NAMUR and Process Alarm Conventions” on page 35). **Failed** digital outputs (DO2, DO4 and DO6; see “Output Connectors Factory Set States” on page 27) become set to their failed state (open) (see “Digital Output Logic and Wiring” on page B87) while all other outputs (digital or analog) remain unchanged and perform as usual.
- 5 Prepare the system to switch from live stream to validation gas bottle.
- 6 Connect the validation gas bottle to the gas input port and make sure that it is ready for the switch from live stream.
- 7 Switch stream to the validation gas bottle and note the required information.
- 8 Switch back to live stream and disconnect the validation gas bottle.
- 9 Wait until measurements return to their normal/expected values.
- 10 Once the measured values have returned to normal, go back to the **Validation** panel (**Maintenance > Validation** [see Figure 67]), click the **Validation Mode** toggle button, then click **Apply**.

NOTE: The validation mode remains active after a Web page refresh but is cancelled after a manual reboot

Exporting Service Logs


Occasionally, you will need to export Sensi+ service logs to send over to ABB service representatives.

NOTE: You need administrator or maintenance access rights to perform this operation.

To do so:

- 1 In the Sensi+ application sidebar, select **Maintenance > Service > Export Service Logs**

Figure 68 Maintenance Export Service Logs Panel



- 2 In the **Export Service Logs** panel, click **Export**.

Sensi+ creates then exports a .zip file of all analyzer service logs to the default **Downloads** folder¹.


¹ Saving behavior and options vary depending on your browser.

Performing Advanced Troubleshooting

Performing advanced troubleshooting is reserved for personnel who has received the appropriate training. During this training, they will have received all the instructions needed to understand the underlying analyzer behavior.

An advanced troubleshooting panel is accessible from the Sensi+ application sidebar under **Maintenance > Advanced**.

Figure 69 Advanced Maintenance Panel



Servicing Analyzer Parts

Over the life of the analyzer, you may need to replace the gas cell or the pump manifold. Once these operations are performed, you will need to change information regarding these parts. The following sections explain how to change this information.

Replacing the Gas Cell



NOTICE


A detailed procedure to physically replace a gas cell is covered and made available during Sensi+ trainings.

After physically replacing the analyzer gas cell, you will need to load the gas cell configuration file and reset the usage counter.

To do so:

- 1 In the Sensi+ application sidebar, select **Maintenance > Service > Replace Cell**

Figure 70 Maintenance Replace Cell Panel



- 2 At the bottom of the pane, click **Load Cell Configuration File**. A standard Windows® **Open** dialog box appears where you can browse and locate the configuration file that you need to load.
- 3 Once located, open the configuration file.
- 4 Toggle the **Reset Usage Counter** switch.
- 5 Click **Apply**.
- 6 Click **Reboot instrument**.

This will complete the replacement of your analyzer gas cell.

Replacing the Pump Manifold



NOTICE


A detailed procedure to physically replace a gas pump manifold is covered and made available during Sensi+ trainings.

After physically replacing the pump manifold, you will need to reset the usage counter and the pump manifold states.

To do so:

- 1 In the Sensi+ application sidebar, select **Maintenance > Service > Replace Pump Manifold**

Figure 71 Maintenance Replace Pump Manifold Panel



- 2 Toggle the **Reset Usage Counter** switch.

- 3 Toggle the **Reset States** switch.

- 4 Click **Apply**.

- 5 Click **Reboot instrument**.

This will complete the replacement of your pump manifold.

About Your Sensi+ Gas Analyzer


Should you need to contact the ABB after-sales service for troubleshooting purposes, you might be asked to provide specific information about your analyzer. This information is accessed either directly on the analyzer physical screen or remotely from the analyzer local display panel in the Web remote interface.

To access this information:

- 1 In the Sensi+ application sidebar, select **Maintenance > Analyzer Local Display**. The exact information displayed on the analyzer physical screen appears on the remote interface.

NOTE: The first of four dots is highlighted at the bottom of the analyzer local display. These dots are **panel identifiers** to help you navigate through the information panels of the local display.

Figure 72 Analyzer Local Display in the Sensi+ Application




- 2 Click on the **Analyzer Local Display** page.
- 3 On your computer keyboard, press the right arrow twice or reach the third panel of the local display. This gives you access to some basic mechanical information about the analyzer, including a QR code.

NOTE: From the Web remote interface, you can use all keyboard arrow keys (up, down, left, right) to navigate through the various local graphical user interface (GUI) screens, as you would with gesture on the real local GUI.


NOTE: The QR codes give you access to the ABB web product page.

Figure 73 Analyzer Local Display Basic Mechanical Data



- 4 Press the right arrow one more time to reach the fourth panel of the local display. This gives you access to various software and firmware data about the analyzer, including a QR code.

Figure 74 Analyzer Local Display Basic Software Data



Backing Up the Analyzer System

Before performing software updates (see “Installing Software Updates” on page 75) or serious troubleshooting tasks, it is recommended to backup the complete analyzer system and not just system results and events (see “Managing Reports” on page 59).



NOTICE

You will need the following to perform a complete analyzer backup:

- the latest software package (GLA533NG_Vx.x.x.ZIP, where x.x.x is the package software version) available [here](#).
- a 128 GB (minimum) exFAT-formatted USB storage device (NOT labelled “ABB_USB”).
An external SSD drive is recommended)

THIS PROCEDURE WILL STOP ANALYZER OPERATION. Make sure that you manage the impacts of such a stoppage on your process before proceeding.

To perform the analyzer backup:


- 1 Connect the USB storage device to the computer where the software package is available.
- 2 Extract the following files on the USB storage device.

Figure 75 Extracting files to the USB storage device



- 3 Copy the following files from the **SCRIPTS_ARCHIVE** folder to the **SCRIPTS** folder.

Figure 76 Copying files to the SCRIPTS folder



- 4 While the Sensi+ is running, connect the USB storage device in the external USB service port. Upon doing so, a series of events will happen automatically:
 - The USB indicator on the Sensi+ local display (bottom left of the screen) will briefly light up when the storage device is detected:
 - The backup script closes the Sensi+ application and the desktop appears.
 - Files are backed up.
 - The Sensi+ application restarts.
- 5 When you see the white screen with the ABB logo, disconnect the USB storage device from the Sensi+.
- 6 Connect the USB storage device to your computer and verify that a folder named **FROM_INSTRUMENT** has been created.
- 7 Verify that the Sensi+ is operating properly.

NOTE: Upon completion of the analyzer backup, delete **the content** of the SCRIPTS folder on the USB storage device.

Installing Software Updates

At some point in the future, you might be asked by ABB service representatives to update your analyzer software. Software updates can only be performed locally via a USB key.

Before performing any software update, it is **strongly recommended** to export your system results and events (see “Managing Reports” on page 59) as well as a complete analyzer backup (see “Backing Up the Analyzer System” on page 73).

NOTICE



You will need the following to perform a complete software update:


- the latest software package (GLA533NG_Vx.x.x.ZIP, where x.x.x is the package software version) available [here](#).
- an 8 GB (minimum) exFAT-formatted USB storage device (NOT labelled “ABB_USB”).

THIS PROCEDURE WILL STOP ANALYZER OPERATION. Make sure that you manage the impacts of such a stoppage on your process before proceeding.

To perform the software update:

- 1 Make sure that the current version of the analyzer software is 1.1.x or later.

Figure 77 Verifying analyzer software version on the analyzer display



NOTICE



If an older version is installed (pilot versions) **CONTACT ABB** as remote assistance is required to perform the update of your device. **Do not perform the other steps of this procedure.**

- 2** Check the content of the software package:

Figure 78 Content of the GLA533NG_Vx.x.x.ZIP Package






Figure 79 Content of the LIVE_IMAGE Folder



- 3** From the software package, unzip the folder **LIVE_IMAGES** to the root of the USB storage device.
The content on the USB storage device should be as follows:

Figure 80 Content of the USB Storage Device



- 4** While the analyzer is running, connect the USB storage device in the external USB **SERVICE** port.
5 Power the analyzer OFF, then ON.
6 Follow the instruction displayed on the analyzer screen.



NOTICE

DO NOT POWER OFF THE ANALYZER DURING THE UPDATE.

7 WHEN THE REQUEST APPEARS on screen, disconnect the USB storage device.

The instrument will reboot automatically.

8 On the analyzer screen, make sure that the new software version corresponds to the one expected.

9 Power OFF the analyzer for 10 seconds, then ON again.

10 Make sure that the analyzer operates as expected and that its configurations are still valid.

If there is no other analyzer software to update, ABB recommends deleting the content of the USB storage device.

Page intentionally left blank

APPENDIX A


The Local Graphical User Interface

The Sensi+ gas analyzer screen displays a graphical user interface (GUI) (Measurements panel; see Figure 82 on page A80) once the start-up sequence is completed. The following pages provide further details on the information available on the various information panels that can be displayed.

You navigate through the information panels by swiping your hand in front of the gesture sensors located below the screen (refer to the Sensi+ Installation and Commissioning Guide if you need to locate the gesture sensors).

Hand swipes up, down, left, and right, made one inch in front of gesture sensors, allow you to access the different information panels, as illustrated below.

Figure 81 Gesture navigation



Information Panels

The following sections provide more details on the various information panels accessible on the gas analyzer screen.

For more information on the configuration of the displayed units of measurement, alarms and alarm thresholds, as well as a more complete description of the various types of alarms, see the appropriate sections elsewhere in this guide.


You cannot modify the information displayed directly from the analyzer GUI.

Measurements Panel

This is the main panel indicating the contaminants measured, the measurements themselves, and the general trends (see “Configuring Gas Measurement Units” on page 15, and “Configuring Gas Parameters” on page 17), as well as the presence of process and NAMUR alarms (see “Introducing NAMUR and Process Alarm Conventions” on page 35).

NOTE: The NAMUR and process alarms colors (cyan, amber, red) carry the same meaning throughout the GUI.

Figure 82 Measurements Panel



Non-Linear Trend Panels

Non-linear trend panels use warning and alarm threshold limits (illustrated by the cyan, amber and red colors) as the Y-axis separation. Each contaminant has its own non-linear trend panel.

These panels are designed to specifically highlight transitions between normal contaminant concentration values and outlying concentration values. They constitute a more detailed view of the non-linear trend graphics displayed in the Measurements panel (see Figure 82 on page A80)

Figure 83 Non-Linear Thread Panel




Y-axis threshold-based
indicators

Linear Trend Panels

In linear trend panels, the scaling gives a linear representation of the measured values but less appreciation of the alarm and warning thresholds. Each contaminant has its own non-linear trend panel.

The main difference with non-linear trend panels is the Y-axis scaling.


Figure 84 Linear Trend Panel



Alarms

The alarms panel displays the various ongoing alarms that the analyzer is experiencing. You cannot manage these alarms (acknowledgment, filtering, etc.) from the local GUI. You must connect to the analyzer via the Web remote interface (as explained in the guide) and follow the instructions given in “Managing Alarms” on page 35 and “Managing Events” on page 49).

Figure 85 Alarms Panel




Diagnostics

The diagnostic panel provides information on the state of important analyzer mechanical components (pump and block valve).

The QR code on the right directs you to the ABB web product page.

Figure 86 Diagnostics Panel



System Information

The system information panel provides technical information specific to your analyzer. The QR code on the right directs you to the ABB web product page.

Figure 87 System Information Panel



Page intentionally left blank

APPENDIX B

Digital Output Logic and Wiring

Logic

Below is an example for two critical parameters reported via digital outputs and how external equipment/wiring needs to be planned accordingly:

	Healthy (energized)	
	Failed (open)	
Tariff High High Limit Reached	Tariff limit exceeded (pipe shut off)	
	Normal level (pipe open)	

Wiring

Solid state relays require to be wired in a specific way to ensure proper operation. The following wirings must be matched.

Figure 88 Low-Side Switch Wiring (left) and High-Side Switch Wiring (right)



Page intentionally left blank

APPENDIX C

Modbus Table

Acquisition blocks are in sync with the data acquisition (rate every ~1.5s).

Health Monitoring blocks are not necessarily in sync with the acquisition and may be read at slower rate if desired

Configuration block is not in sync with the acquisition and read at slower rate.

Table

Start Address	Length	IPC Value Name	Value Type	Description	Bytes	Physical Units	Value Range
30000		Input registers Modbus standard offset		Function FC=04 Read input registers (3x) (read-only)			See "TCP/IP Modbus parameters details" on page C106
1000 Acquisition UINT16							
1000	1	H2S_UnitID	UINT16	UnitID selected by user (or default configuration)	2	ppmv (default)	See "UnitID" on page C101
1001	1	CO2_UnitID	UINT16	UnitID selected by user (or default configuration)	2	ppmv (default)	See "UnitID" on page C101
1002	1	H2O_UnitID	UINT16	UnitID selected by user (or default configuration)	2	ppmv (default)	See "UnitID" on page C101
1003	1	spare_UnitID	UINT16	UnitID selected by user (or default configuration)	2	ppmv (default)	See "UnitID" on page C101
1004	1	temp_UID	UINT16	Temperature UnitID selected by user (or default configuration)	2	C (default)	See "UnitID" on page C101
1005	1	press_UID	UINT16	Pressure UnitID selected by user (or default configuration)	2	hPa (default)	See "UnitID" on page C101
1006	1	nbrProcessAlarms	UINT16	Number of current Process alarms	2	N/A	
1007	1	nbrNamurAlarms	UINT16	Number of current NAMUR alarms	2	N/A	

Start Address	Length	IPC Value Name	Value Type	Description	Bytes	Physical Units	Value Range
1008	1	activePumpId	UINT16	Current active pump	2	N/A	0 (OFF),1,2,3
1009	1	laser0_wicState	UINT16	Current internal dataprocessing state and flags (fit status, autotune request)	2	N/A	See "WIC States" on page C101
1010	1	laser1_wicState	UINT16	Current internal dataprocessing state and flags (fit status, autotune request)	2	N/A	See "WIC States" on page C101
1011	1	spare_wicState	UINT16	Current internal dataprocessing state and flags (fit status, autotune request)	2	N/A	See "WIC States" on page C101
1100 Acquisition UINT32							
1100	2	H2S_Status	UINT32	Gas' Process Alarms and Quality	4	N/A	See "Bitfield PROCESS" on page C101 and "Bitfield NAMUR" on page C102
1102	2	CO2_Status	UINT32	Gas' Process Alarms and Quality	4	N/A	See "Bitfield PROCESS" on page C101 and "Bitfield NAMUR" on page C102
1104	2	H2O_Status	UINT32	Gas' Process Alarms and Quality	4	N/A	See "Bitfield PROCESS" on page C101 and "Bitfield NAMUR" on page C102
1106	2	Spare_Status	UINT32	Gas' Process Alarms and Quality	4	N/A	See "Bitfield PROCESS" on page C101 and "Bitfield NAMUR" on page C102
1108	2	processStates	UINT32	Global Process Status Corresponding icon displayed on local HMI ("process" - top right) (Only most severe alarms)	4	N/A	See "Bitfield PROCESS" on page C101

Start Address	Length	IPC Value Name	Value Type	Description	Bytes	Physical Units	Value Range
1110	2	namurStates	UINT32	Global NAMUR Status Corresponding icon displayed on local HMI ("namur" - top right) (Only most severe alarms)	4	N/A	See "Bitfield NAMUR" on page C102
1112	2	timestamp_System	UINT32	Monotonic time (always increased since boot time, delta time)	4	s	Monotonic time relative to last system boot
1114	2	timestamp_UTC	UINT32	Clock time (representative of instrument time) Corresponds to the start time of the current acquisition	4	s	Number of seconds since 1970-01-01 (epoch time)
1116	2	StreamId	UINT32	0 = Sampling 8 = Validation	4	N/A	[0 to 8]
1118	2	dataQuality	UINT32	Reserved for future use	4	N/A	
1120	2	processAlarmFlag	UINT32	All active process flags	4	N/A	All gases process status OR'ed See "Bitfield PROCESS" on page C101
1122	2	acqErrorReg	UINT32	Errors when reading hardware devices for auxilliary measurements (temperature sensors, pressure sensors, etc)	4	N/A	See "Acquisition Error Registry" on page C102
1124	2	eventsLaserReg	UINT32	Specific NAMUR alarms detected on one or more laser that impact measurement quality. Sets all its associated gas(es) to uncertain quality.	4	N/A	Bitfield: 0 = ok 1 = first laser 2 = second laser 4 = third laser

Start Address	Length	IPC Value Name	Value Type	Description	Bytes	Physical Units	Value Range
1126	2	eventsReg	UINT32	Bitfield that contains information of active alarms (NAMUR) that impact quality of ALL gases measurements (pressure, temperature, interlock)	4	N/A	See “Events Registry” on page C102
1128	2	interlockStatus	UINT32	Enclosure interlock status	4	N/A	0 = Good (both compartments well closed), 1 = EBOX interlock active (compartment open), 2 = OBOX interlock active (compartment open)
1130	2	configuration_checksum	UINT32	For future use	4	N/A	Future use
1200	Acquisition UINT64						
1200	4	AcquisitionId	UINT64	Acquisition counter since commissioning	8	N/A	
1300	Acquisition FLOAT32						
1300	2	H2S_Concentration	FLOAT32	Filtered value of the H ₂ S concentration	4	See “UnitID” on pageC101	Configured units
1302	2	H2S_Min	FLOAT32	Min. display range & 4–20 mA conversion range	4	See “UnitID” on pageC101	
1304	2	H2S_Max	FLOAT32	Max. display range & 4–20 mA conversion range	4	See “UnitID” on pageC101	
1306	2	H2S_High_High_Threshold	FLOAT32	Alarm High High threshold. By default linked to DO_1	4	See “UnitID” on pageC101	Configured units
1308	2	H2S_SpanGain	FLOAT32	Span gain user configuration	4	N/A	Configured units
1310	2	H2S_ZeroOffset	FLOAT32	Zero offset user configuration	4	See “UnitID” on pageC101	Configured units

Start Address	Length	IPC Value Name	Value Type	Description	Bytes	Physical Units	Value Range
1312	2	CO2_Concentration	FLOAT32	Filtered value of the CO ₂ concentration	4	See "UnitID" on pageC101	Configured units
1314	2	CO2_Min	FLOAT32	Min. display range & 4-20 mA	4	See "UnitID" on pageC101	
1316	2	CO2_Max	FLOAT32	Max. display range & 4-20 mA	4	See "UnitID" on pageC101	
1318	2	CO2_High_High_Threshold	FLOAT32	Alarm High High threshold. By default linked to DO_3	4	See "UnitID" on pageC101	Configured units
1320	2	CO2_SpanGain	FLOAT32	Span gain user configuration	4	N/A	Configured units
1322	2	CO2_ZeroOffset	FLOAT32	Zero offset user configuration	4	See "UnitID" on pageC101	Configured units
1324	2	H2O_Concentration	FLOAT32	Filtered value of the H ₂ O concentration	4	See "UnitID" on pageC101	Configured units
1326	2	H2O_Min	FLOAT32	Min. display range & 4-20 mA	4	See "UnitID" on pageC101	
1328	2	H2O_Max	FLOAT32	Max. display range & 4-20 mA	4	See "UnitID" on pageC101	
1330	2	H2O_High_High_Threshold	FLOAT32	Alarm High High threshold. By default linked to DO_5	4	See "UnitID" on pageC101	Configured units
1332	2	H2O_SpanGain	FLOAT32	Span gain user configuration	4	N/A	Configured units
1334	2	H2O_ZeroOffset	FLOAT32	Zero offset user configuration	4	See "UnitID" on pageC101	Configured units
1336	2	Spare_Concentration	FLOAT32	Filtered value of the spare concentration	4	See "UnitID" on pageC101	Configured units

Start Address	Length	IPC Value Name	Value Type	Description	Bytes	Physical Units	Value Range
1338	2	Spare_Min	FLOAT32	Min. display range & 4–20 mA	4	See “UnitID” on pageC101	
1340	2	Spare_Max	FLOAT32	Max. display range & 4–20 mA	4	See “UnitID” on pageC101	
1342	2	Spare_High_High_Threshold	FLOAT32	Alarm High High threshold By default linked to DO_7	4	See “UnitID” on pageC101	Configured units
1344	2	Spare_SpanGain	FLOAT32	Span gain user configuration	4	N/A	Configured units
1346	2	Spare_ZeroOffset	FLOAT32	Zero offset user configuration	4	See “UnitID” on pageC101	Configured units
1348	2	gasPressure	FLOAT32	Pressure of the gas cell	4	See “UnitID” on pageC101	native units
1350	2	gasTemperature	FLOAT32	Temperature of the gas cell	4	See “UnitID” on pageC101	native units
1352	2	ambientPressure	FLOAT32	OBOX (bottom compartment) ambient pressure	4	See “UnitID” on pageC101	
1354	2	ambientTemperature	FLOAT32	OBOX (bottom compartment) ambient temperature	4	See “UnitID” on pageC101	
1356	2	eboxPressure	FLOAT32	EBOX (upper compartment) pressure	4	See “UnitID” on pageC101	
1358	2	eboxTemperature	FLOAT32	EBOX (upper compartment) temperature	4	See “UnitID” on pageC101	
1360	2	annunPressure	FLOAT32	Annunciation Pressure: OBOX-EBOX	4	See “UnitID” on pageC101	
1362	2	laser0_model0_baseline_A	FLOAT32	Indication of laser signal	4	N/A	

Start Address	Length	IPC Value Name	Value Type	Description	Bytes	Physical Units	Value Range
1364	2	laser0_model0_ringdownModel_ringdown	FLOAT32	Indication of laser ringdown	4	s	
1366	2	laser0_pcbaTemperature	FLOAT32	Laser 0 PCB temperature	4	C	
1368	2	laser0_tecTemperature	FLOAT32	Laser 0 TEC temperature	4	C	
1370	2	laser0_tecTemperatureSetpoint	FLOAT32	Laser 0 TEC temperature setpoint	4	C	
1372	2	laser1_model0_baseline_A	FLOAT32	Indication of laser signal	4	N/A	
1374	2	laser1_model0_ringdownModel_ringdown	FLOAT32	Indication of laser ringdown	4	s	
1376	2	laser1_pcbaTemperature	FLOAT32	Laser 1 PCB temperature	4	C	
1378	2	laser1_tecTemperature	FLOAT32	Laser 1 TEC temperature	4	C	
1380	2	laser1_tecTemperatureSetpoint	FLOAT32	Laser 1 TEC temperature setpoint	4	C	
1382	2	spare_model0_baseline_A	FLOAT32	Indication of laser signal	4	N/A	
1384	2	spare_model0_ringdownModel_ringdown	FLOAT32	Indication of laser ringdown	4	s	
1386	2	spare_pcbaTemperature	FLOAT32	Spare PCB temperature	4	C	
1388	2	spare_tecTemperature	FLOAT32	Spare TEC temperature	4	C	
1390	2	spare_tecTemperatureSetpoint	FLOAT32	Spare TEC temperature setpoint	4	C	
1500 Health Monitoring UINT16							
1500	1	s350_pump_disabledcount	UINT16	Number of pumps tagged 'Disabled'	2	N/A	0,1,2,3
1501	1	s370_DI_value	UINT16	Bit wise : State of each DI	2	N/A	Bit wise : bit0=RESERVED bit1=input #1 bit2=input #2
1502	1	s370_DO_status	UINT16	Bit wise : State of each DO	2	N/A	Bit wise : bit0=RESERVED bit1=output #1 bit2=output #2 ... , bit10=output #10

Start Address	Length	IPC Value Name	Value Type	Description	Bytes	Physical Units	Value Range
1600 Health Monitoring UINT32							
1600	2	c155s0_error	UINT32	Laser 0 error register	4	N/A	See “Bit Wise c155sx ERROR” on page C103
1602	2	c155s0_status	UINT32	Laser 0 status register	4	N/A	See “Bit Wise c155sx STATUS” on page C103
1604	2	c155s1_error	UINT32	Laser 1 error register	4	N/A	See “Bit Wise c155sx ERROR” on page C103
1606	2	c155s1_status	UINT32	Laser 1 status register	4	N/A	See “Bit Wise c155sx STATUS” on page C103
1608	2	c155s2_error	UINT32	Laser Slot 2 error register	4	N/A	See “Bit Wise c155sx ERROR” on page C103
1610	2	c155s2_status	UINT32	Laser Slot 2 status register	4	N/A	See “Bit Wise c155sx STATUS” on page C103
1612	2	s350_error	UINT32	s350 Board Error	4	N/A	See “Bit Wise s350 ERROR” on page C103
1614	2	s350_status	UINT32	s350 Board Status	4	N/A	See “Bit Wise s350 STATUS” on page C104 0 = OK, error otherwise
1616	2	s350_pump_speed	UINT32	Pump speed of active pump in Hz	4	Hz	
1618	2	s350_uptime	UINT32	Up time of MCU in seconds	4	seconds	
1620	2	s370_comm_status	UINT32	Communication status with the s370 board	4	N/A	0 = OK, 1 = Comm error with board
1622	2	s370_error	UINT32	s370 Board Error	4	N/A	See “Bit Wise s370 ERROR” on page C104
1624	2	s370_output420_status_1	UINT32	s370 4-20mA status register 1	4	N/A	See “Bit Wise output420 STATUS” on page C104
1626	2	s370_output420_status_2	UINT32	s370 4-20mA status register 2	4	N/A	See “Bit Wise output420 STATUS” on page C104
1628	2	s370_output420_status_3	UINT32	s370 4-20mA status register 3	4	N/A	See “Bit Wise output420 STATUS” on page C104

Start Address	Length	IPC Value Name	Value Type	Description	Bytes	Physical Units	Value Range
1630	2	s370_output420_status_4	UINT32	s370 4-20mA status register 4	4	N/A	See "Bit Wise output420 STATUS" on page C104
1632	2	s380_comm_status	UINT32	Communication status with the s380 board	4	N/A	0 = OK, 1 = Comm error with board
1634	2	laser0_usage_time	UINT32	Total number of hours of usage	4	hours	
1636	2	laser1_usage_time	UINT32	Total number of hours of usage	4	hours	
1638	2	spare_usage_time	UINT32	Total number of hours of usage	4	hours	
1640	2	pump1_usage_time	UINT32	Total number of hours of usage	4	hours	
1642	2	pump2_usage_time	UINT32	Total number of hours of usage	4	hours	
1644	2	pump3_usage_time	UINT32	Total number of hours of usage	4	hours	
1646	2	ebox_usage_time	UINT32	Total number of hours of usage	4	hours	
1700 Health Monitoring UINT64							
1700	4	Health Monitoring Id	UINT64	Health Monitoring counter since commissioning	8	N/A	
1704	4	Status	UINT64	RESERVED for future use	8	N/A	
1708	4	Concatenated error flag1	UINT64	Concatenated error flag for future use	8	N/A	
1712	4	Concatenated error flag2	UINT64	Concatenated error flag for future use	8	N/A	
1800 Health Monitoring FLOAT32							
1800	2	c155s0_pd_monitor	FLOAT32	Laser diode power monitor in A	4	A	
1802	2	c155s0_tec_current	FLOAT32	Laser 0 TEC current in A	4	A	
1804	2	c155s0_tec_voltage	FLOAT32	Laser 0 TEC voltage in V	4	V	
1806	2	c155s0_uptime	FLOAT32	Up time of MCU in seconds	4	seconds	
1808	2	c155s1_pd_monitor	FLOAT32	Laser diode power monitor in A	4	A	
1810	2	c155s1_tec_current	FLOAT32	Laser 1 TEC current in A	4	A	
1812	2	c155s1_tec_voltage	FLOAT32	Laser 1 TEC voltage in V	4	V	

Start Address	Length	IPC Value Name	Value Type	Description	Bytes	Physical Units	Value Range
1814	2	c155s1_uptime	FLOAT32	Up time of MCU in seconds	4	seconds	
1816	2	c155s2_pd_monitor	FLOAT32	Laser diode power monitor in A	4	A	
1818	2	c155s2_tec_current	FLOAT32	Laser slot2 TEC current in A	4	A	
1820	2	c155s2_tec_voltage	FLOAT32	Laser slot2 TEC voltage in V	4	V	
1822	2	c155s2_uptime	FLOAT32	Up time of MCU in seconds	4	seconds	
1824	2	proc_capacity	FLOAT32	Processing Queue size/max	4	N/A	
1826	2	proc_procTime	FLOAT32	Data Processing Time	4	seconds	
1828	2	s350_gascellctrl_outduty	FLOAT32	Proportional valve duty cycle in % [0:100]	4	%	
1830	2	s350_gascellctrl_setpoint	FLOAT32	Pressure setpoint from 0 to 1 (0:min,1:max of pressure device range)	4	hPa	
1832	2	s350_heater_current	FLOAT32	Current in A	4	A	
1834	2	s350_mcudtemp	FLOAT32	MCU temperature in C	4	C	
1836	2	s350_pump_ctrl_speed	FLOAT32	Pump speed in % [0:100]	4	%	
1838	2	s350_pump_current	FLOAT32	Current in A	4	A	
1840	2	s350_valve_current	FLOAT32	Current in A	4	A	
1842	2	s370_AO_1	FLOAT32	4-20ma output current in mA	4	mA	
1844	2	s370_AO_2	FLOAT32	4-20ma output current in mA	4	mA	
1846	2	s370_AO_3	FLOAT32	4-20ma output current in mA	4	mA	
1848	2	s370_AO_4	FLOAT32	4-20ma output current in mA	4	mA	
1850	2	s370_readout_1030V_input	FLOAT32	Power Entry Voltage	4	V	
1852	2	sbc_cpuTemp	FLOAT32	Temperature of the CPU	4	C	
1854	2	sbc_driveStorageAvail	FLOAT32	% of disk storage available	4	%	
1856	2	sbc_memoryAvail	FLOAT32	% of memory available	4	%	

Start Address	Length	IPC Value Name	Value Type	Description	Bytes	Physical Units	Value Range
1858	2	s370_output420_Vloop_AO_1	FLOAT32	Analog Output (4-20mA) Loop Voltage	4	V	
1860	2	s370_output420_Vloop_AO_2	FLOAT32	Analog Output (4-20mA) Loop Voltage	4	V	
1862	2	s370_output420_Vloop_AO_3	FLOAT32	Analog Output (4-20mA) Loop Voltage	4	V	
1864	2	s370_output420_Vloop_AO_4	FLOAT32	Analog Output (4-20mA) Loop Voltage	4	V	
1866	2	s370_output420_Temperature_AO_1	FLOAT32	Analog Output (4-20mA) IC Temperature	4	C	
1868	2	s370_output420_Temperature_AO_2	FLOAT32	Analog Output (4-20mA) IC Temperature	4	C	
1870	2	s370_output420_Temperature_AO_3	FLOAT32	Analog Output (4-20mA) IC Temperature	4	C	
1872	2	s370_output420_Temperature_AO_4	FLOAT32	Analog Output (4-20mA) IC Temperature	4	C	
2000 Instrument Configuration							
2000	1	s370_serial_config_port#1	UINT16	Serial port#1 configuration (Future use)	2	N/A	See "S370 serial config" on page C105
2001	1	s370_serial_config_port#2	UINT16	Serial port#2 configuration (Future use)	2	N/A	See "Bit Wise output420 STATUS" on page C104
2002	1	s370_AO_1 output420_config	UINT16	AO_1 configuration (active/passive)	2	N/A	See "Bit Wise S370 output420 config" on page C104
2003	1	s370_AO_2 output420_config	UINT16	AO_2 configuration (active/passive)	2	N/A	See "Bit Wise S370 output420 config" on page C104
2004	1	s370_AO_3 output420_config	UINT16	AO_3 configuration (active/passive)	2	N/A	See "Bit Wise S370 output420 config" on page C104
2005	1	s370_AO_4 output420_config	UINT16	AO_4 configuration (active/passive)	2	N/A	See "Bit Wise S370 output420 config" on page C104

Start Address	Length	IPC Value Name	Value Type	Description	Bytes	Physical Units	Value Range
2006	1	instrument_model	UINT16	Instrument model i.e: GLA533-NG-WWW-XX-YYY-AL-R-ZZ	2	N/A	
2007	1	sw_app_version_major	UINT16	SW application version (Major,Minor,Patch)	2	N/A	
2008	1	sw_app_version_minor	UINT16	SW application version (Major,Minor,Patch)	2	N/A	
2009	1	sw_app_version_patch	UINT16	SW application version (Major,Minor,Patch)	2	N/A	
2010	1	workspace_version_major	UINT16	Workspace version (Major,Minor,Patch)	2	N/A	
2011	1	workspace_version_minor	UINT16	Workspace version (Major,Minor,Patch)	2	N/A	
2012	1	workspace_version_patch	UINT16	Workspace version (Major,Minor,Patch)	2	N/A	
2013	2	Gas Configuration	UINT16	RESERVED for future use	2	N/A	
TOTAL (address space of 16 bits)	296			TOTAL (Bytes)	590	"	"

Description Details

UnitID

1	NoUnits
2	C
3	F
4	K
5	W
6	mW
7	kW
8	cm-1
9	micron
11	ppmv
12	%vol
13	mg/m3
20	g
21	Volts
22	hPa
23	m
24	A
25	s
26	mV
27	kV

WIC States

Low byte

0	disabled (no correction in case of incorrect fit diagnostic)
1	warmup (instrument startup procedure/stabilization)
2	autotune (automated spectral alignment in progress)
3	operation (normal operation measurement mode)

High byte

256	bad_fit
512	req_auto_tune

Bitfield PROCESS

PROCESS_NO_ERROR = 0x00
PROCESS_NOTIFICATION = 0x20
PROCESS_WARNING = 0x40
PROCESS_ALARM = 0x80

Bitfield NAMUR

```
NAMUR_NO_ERROR = 0x00  
NAMUR_FAILURE = 0x01  
NAMUR_FUNCTION_CHECK = 0x02  
NAMUR_OUT_OF_SPEC = 0x04  
NAMUR_MAINTENANCE = 0x08
```

Bitfield QUALITY

```
QUALITY_GOOD=0x00000000U  
QUALITY_UNCERTAIN=0x00100000U  
QUALITY_UNCERTAIN_SENSOR_NOT_ACCURATE=0x00380000U (trending)
```

Acquisition Error Registry

```
const uint32_t acquisition = 0x0001  
const uint32_t getFeedback = 0x0002  
const uint32_t getThermistor = 0x0004  
const uint32_t readOBoxSensors = 0x0008  
const uint32_t readEBoxSensors = 0x0010  
const uint32_t getPcbTemperature[3] = {laser0 = 0x0020 laser1 = 0x0040 spare = 0x0080}  
const uint32_t getTecTemperature[3] = {laser0 = 0x0100 laser1 = 0x0200 spare = 0x0400}  
const uint32_t getTecSpTemperature[3] = {laser0 = 0x0800 laser1 = 0x1000 spare = 0x2000}
```

Events Registry

```
static constexpr uint32_t EVENT_CELL_TEMPERATURE_LL = 0x0001;  
static constexpr uint32_t EVENT_CELL_TEMPERATURE_HH = 0x0002;  
static constexpr uint32_t EVENT_CELL_PRESSURE_LL = 0x0004;  
static constexpr uint32_t EVENT_CELL_PRESSURE_HH = 0x0008;  
static constexpr uint32_t EVENT_OBOX_TEMPERATURE_LL = 0x0010;  
static constexpr uint32_t EVENT_OBOX_TEMPERATURE_HH = 0x0020;  
static constexpr uint32_t EVENT_OBOX_PRESSURE_LL = 0x0040;  
static constexpr uint32_t EVENT_OBOX_PRESSURE_HH = 0x0080;  
static constexpr uint32_t EVENT_EBOX_INTERLOCK = 0x0100;  
static constexpr uint32_t EVENT_OBOX_INTERLOCK = 0x0200;
```

Bit Wise c155sx ERROR

0x1=ERROR_EEPROM_DEFAULT_MANUF
0x2=ERROR_EEPROM_DEFAULT_CONFIG
0x4=ERROR_EEPROM_DEFAULT_USER_SPACE
0x8=ERROR_USB_NOT_CONNECTED
0x10=ERROR_ADS124S08_THERM_ERROR
0x20=ERROR_EEPROM_RESET_COUNTER
0x40=ERROR_EEPROM_ERROR
0x80=ERROR_EEPROM_LASER_COUNTER_UPDATE

Bit Wise c155sx STATUS

0x1=STATUS_LASER_ILOCK
0x2=STATUS_MOSFET_CLAMP
0x4=STATUS_I_SOURCE_ENABLE
0x8=STATUS_TEC_CTRL_ON
0x10=STATUS_TEC_CTRL_LOCK
0x100=STATUS_SLOT_ID0
0x200=STATUS_SLOT_ID1
0x400=STATUS_SLOT_ID2
0x10000=STATUS_LASER_HS_ID1
0x20000=STATUS_LASER_HS_ID2
0x40000=STATUS_LASER_HS_ID3
0x80000=STATUS_LASER_HS_ID4
0x80=ERROR_EEPROM_LASER_COUNTER_UPDATE

Bit Wise s350 ERROR

0x1=ERROR_EEPROM_DEFAULT_MANUF
0x2=ERROR_EEPROM_DEFAULT_CONFIG
0x4=ERROR_EEPROM_DEFAULT_USER_SPACE
0x8=ERROR_USB_NOT_CONNECTED
0x10=ERROR_ADS124S08_THERM_ERROR
0x20=ERROR_ADS124S08_PRESSURE_ERROR
0x40=ERROR_PRESSURE_READ_OVERRUN_ERROR
0x80=ERROR_EEPROM_ERROR

Bit Wise s350 STATUS

0xFF: board revision 0=A, 1=B, 2=C, ...
0x10000=STATUS_LASER_0_RESET
0x20000=STATUS_LASER_1_RESET
0x40000=STATUS_LASER_2_RESET
0x80000=STATUS_LASER_BOOT
0x100000=STATUS_CLIENT_BOOT
0x200000=STATUS_BCKPL_SPARE_4
0x400000=STATUS_BCKPL_SPARE_5

Bit Wise s370 ERROR

0x01=ERROR_EEPROM_DEFAULT_MANUF
0x02=ERROR_EEPROM_DEFAULT_MANUFCOM_CONFIG
0x04=ERROR_EEPROM_DEFAULT_MANUFPOWER_CONFIG
0x08=ERROR_EEPROM_DEFAULT_USER_SPACE
0x10=ERROR_USB_NOT_CONNECTED
0x20=ERROR_UARTBRIDGE1_RXOVERFLOW
0x40=ERROR_UARTBRIDGE2_RXOVERFLOW
0x80=ERROR_EEPROM_ERROR

Bit Wise output420 STATUS

AD5421 fault register (table 19)
0x00FF Vloop/Temperature value
0x0100=Vloop 12V
0x0200=Vloop 6V
0x0400=Temp 100C
0x0800=Temp 140C
0x1000=Iloop under
0x2000=Iloop over
0x4000=PEC
0x8000=SPI

Bit Wise S370 output420 config

General config for 4-20ma, bit wise :
0x1=4-20ma output in active mode (otherwise passive mode)

S370 serial config

0=Unset

1=RS232

2=RS485 full


3=RS485 full term


4=RS485 full RxTx term

5=RS485 half

6=RS485 half term

TCP/IP Modbus parameters details

Port	502
Slave address	1
Default Endianness	Big Endian  <p>The diagram illustrates the memory mapping for a 32-bit integer in Big-endian format. A 32-bit integer is shown in a box labeled "0A0B0C0D". Above it, a vertical stack of memory locations is labeled "Memory" with addresses "a", "a+1", "a+2", and "a+3" below them. Arrows point from each memory location to its corresponding byte value: "a: 0A", "a+1: 0B", "a+2: 0C", and "a+3: 0D". The label "Big-endian" is positioned at the bottom right of the memory stack.</p>
Modbus Register Type	Input Register (read-only)
	Standard offset 30000
	Function FC=04 to read registers



Calculating Zero Offsets and Span Gains



NOTICE

DO NOT modify offsets and gains unless recommended by ABB after-sales service or engineering departments.

Zero offsets and span gains are factory-calibrated on a reference cylinder to optimize analyzer accuracy. To adjust offsets and span gains, you must be logged in as an administrator

Obtaining Calculation Values

To obtain the correct values for span gains:

- 1 In Sensi+, run a pure CH₄ reference gas with a known contaminant concentration.
- 2 After stabilization, note the value read by the analyzer as value **C1reading**.

This value will be compared to a reference concentration defined on certificate **C1ref**.

To obtain the correct values for offsets:

- 1 In Sensi+, run a pure CH₄ reference gas *without* contaminant.
- 2 After stabilization, note the value read by the analyzer as value **C2reading**.

NOTE: In most cases, moisture will always be present, even in a certified dry gas. Before changing H₂O offset it is important to confirm H₂O concentration in the zero reference cylinder.

Calculating Gain Values

The formula to calculate a gain value is: **Span gain = (C1ref – C2ref)/(C1reading – C2reading)**

where:

- **C1ref:** reference concentration from cylinder 1 certificate
- **C1reading:** concentration from cylinder 1 measured with Sensi+
- **C2ref:** reference concentration from cylinder 2 certificate
- **C2reading:** concentration from cylinder 2 measured with Sensi+

Calculating Offset Values

The formula to calculate offsets is : **Offset = C2ref – (C2reading × Span gain)**

where:

- **C2ref:** Reference concentration from cylinder 2 certificate
- **C2reading:** concentration from cylinder 2 measured with Sensi+

NOTE: If offsets are not used, set **C2ref** and **C2reading** at 0

Page intentionally left blank

APPENDIX E

Technical Specifications

The following pages indicate the Sensi+ gas analyzer technical specifications.



NOTICE

While the initial (cold start) accuracy of the sensor is likely to be within specifications, a settling period of approximately 12 hours is strongly recommended to allow electronic components to fully warm up and the internal temperature to stabilize.

Measurement Specifications

	H ₂ S	H ₂ O	CO ₂
Linear range ¹	0–100 ppvm	0–500 ppvm	0–40%
Repeatability ¹	±0.1 ppm or ±1% of reading	±1 ppm or ±1% of reading	±100 ppm or ±1% of reading
Accuracy ¹	±0.2 ppm or ±2% of reading	±2 ppm or ±2% of reading	±300 ppm or ±2% of reading
Minimum detectable range ¹	0.2 ppm	2 ppm	150 ppm
Measurement update time	<2 s	<2 s	<2 s
Rise (fall) time (T10–90) ¹	<10 s	<35 s	<10 s
Trending range ²	100–10,000 ppmv	0–98% RH	0–100%

Electrical Specifications

Voltage input	10.5 to 30.0 V DC
Overvoltage category	1
Electrical installation category	1
Maximum power consumption	50.0 W
Maximum current	10.0 A

¹ As per IEC 61207 definitions

² For safe operation, the maximum trending level shall not be exceeded. For operation at high levels, contact ABB.

Environmental Specifications

Operating temperature	-14 °C to 55 °C (7 °F to 131 °F) (cold range can be extended when installation is using heated shelter/cabinet)
Survival temperature	-18 °C to 60 °C (0 °F to 140 °F)
Shipping/storage temperature	-30 °C to 60 °C (-22 °F to 140 °F)
Operating ambient humidity	5% to 95% RH, non-condensing (applicable to internal parts only)
Installation location	Indoor/outdoor including wet area (excluding flooding)
Pollution degree	2
Operating altitude (max.)	2000 m (6562 ft)

Mechanical Specifications

Overall dimensions (L × W × H)	525 × 385 × 364 mm (20.7 × 15.6 × 14.3 in) (L is 654 mm [25.7 in] with optional Wi-Fi antenna)
Weight	50.0 kg (110 lb)
Interface to electronics	1" NPT or M32, female threads (as selected on order)
Process inlet pressure	35.0–48.0 kPa gauge (5.0–7.5 psig)
Sample flow rate	0.4 SLPM (0.014 scfm)
Enclosure	IP66/NEMA 4X Explosion-proof Flameproof Dual seal with annunciation

Laser

Type	DFB laser diode
Output	50 mW max.
Class	1

Communication

Digital interfaces (internal)	<ul style="list-style-type: none">• 2×RJ45 1000Base-T Ethernet ports• 2×USB ports
Digital interfaces (external)	<ul style="list-style-type: none">• RJ45 1000Base-T Ethernet port• USB port
Protocols	Modbus TCP/IP over Ethernet
Analog interfaces	4 isolated analog 4–20 mA outputs



ABB, Inc.
Measurement & Analytics

3400, rue Pierre-Ardouin
Québec (Québec) G1P 0B2
Canada

Phone:
North America: 1 800 858 3847
Worldwide: +1 418 877 8111

Email:
icos.ca.abb.com

WWW.abb.com/analytical

We reserve the right to make technical changes or modify the contents of this document without prior notice. With regard to purchase orders, the agreed particulars shall prevail. ABB does not accept any responsibility whatsoever for potential errors or possible lack of information in this document.

We reserve all rights in this document and in the subject matter and illustrations contained therein. Any reproduction, disclosure to third parties or utilization of its contents, in whole or in parts, is forbidden without prior written consent from ABB.